

[illegible][illegible]

```

DDDDDDDD DDDDDDDD DDDDDDDD RRRRRRRR I I I I I VV VV EEEEEEEEE RRRRRRRR
DDDDDDDD DDDDDDDD DDDDDDDD RRRRRRRR I I I I I VV VV EEEEEEEEE RRRRRRRR
DD DD DD DD DD DD RR RR VV VV EE EEEEEEEEE RR RR RR
DD DD DD DD DD DD RR RR VV VV EE EEEEEEEEE RR RR RR
DD DD DD DD DD DD RR RR VV VV EE EEEEEEEEE RR RR RR
DD DD DD DD DD DD RR RR VV VV EE EEEEEEEEE RR RR RR
DD DD DD DD DD DD RRRRRRRR II II VV VV EEEEEEEEE RRRRRRRR
DD DD DD DD DD DD RRRRRRRR II II VV VV EEEEEEEEE RRRRRRRR
DD DD DD DD DD DD RR RR II II VV VV EE EEEEEEEEE RR RR
DD DD DD DD DD DD RR RR II II VV VV EE EEEEEEEEE RR RR
DD DD DD DD DD DD RR RR II II VV VV EE EEEEEEEEE RR RR
DDDDDDDD DDDDDDDD DDDDDDDD RR RR II I I I I I VV VV EEEEEEEEE RR RR
DDDDDDDD DDDDDDDD DDDDDDDD RR RR II I I I I I VV VV EEEEEEEEE RR RR

```

```

LL                      IIIII
LL                      IIIII
LL                      III
LL                      III
LL                      III
LL                      III
LL                      III
LL                      III
LL                      III
LL                      III
LL                      III
LL                      III
LL                      III
LL                      III
LL                      III
LLLLLLLLLLLLLLLL      IIIII
LLLLLLLLLLLLLLLL      IIIII
SSSSSSSSSS            SS
SS                     SS
SS                     SS
SS                     SS
SSSSSSS               SSSSSS
SSSSSSS               SSS
SS                     SS
SS                     SS
SS                     SS
SSSSSSSSSS            SSSSSSSSSS
SSSSSSSSSS            SSSSSSSSSS

```

DDDRIVER
Table of contents

- TUS8 DC100 TAPE CARTRIDGE DRIVER M 16

16-SEP-1984 00:19:23 VAX/VMS Macro V04-00

Page 0

(1)	131	EXTERNAL DEFINITIONS
(1)	153	LOCAL DEFINITIONS
(1)	330	LOCAL MACRO DEFINITIONS
(1)	418	DRIVER PROLOGUE TABLE
(1)	472	DRIVER DISPATCH TABLE
(1)	492	FUNCTION DECISION TABLE
(1)	590	TUS8 UNIT INITIALIZATION
(1)	680	INIT UNIT
(1)	772	SND_PKT_NOINT
(1)	823	DUMP_RECVR_BUF
(1)	867	STARTIO ROUTINE
(1)	1228	COMMON EXIT ROUTINE
(1)	1247	Controller error handler
(1)	1279	TIMEOUT and POWERFAIL recovery
(1)	1324	RESET CONTROLLER
(1)	1391	REGISTER DUMP ROUTINE
(1)	1425	INTERRUPT SERVICE ROUTINE
(1)	1465	LOCAL SUBROUTINES
(1)	1506	GET_PACKET_C
(1)	1636	SEND_PACKET_C
(1)	1746	GET_PACKET_U
(1)	1876	SEND_PACKET_U

```
0000 1      .TITLE DDDRIVER - TU58 DC100 TAPE CARTRIDGE DRIVER
0000 2      .IDENT 'V04-000'
0000 3
0000 4
0000 5      *****
0000 6      *
0000 7      * COPYRIGHT (c) 1978, 1980, 1982, 1984 BY
0000 8      * DIGITAL EQUIPMENT CORPORATION, MAYNARD, MASSACHUSETTS.
0000 9      * ALL RIGHTS RESERVED.
0000 10     *
0000 11     * THIS SOFTWARE IS FURNISHED UNDER A LICENSE AND MAY BE USED AND COPIED
0000 12     * ONLY IN ACCORDANCE WITH THE TERMS OF SUCH LICENSE AND WITH THE
0000 13     * INCLUSION OF THE ABOVE COPYRIGHT NOTICE. THIS SOFTWARE OR ANY OTHER
0000 14     * COPIES THEREOF MAY NOT BE PROVIDED OR OTHERWISE MADE AVAILABLE TO ANY
0000 15     * OTHER PERSON. NO TITLE TO AND OWNERSHIP OF THE SOFTWARE IS HEREBY
0000 16     * TRANSFERRED.
0000 17     *
0000 18     * THE INFORMATION IN THIS SOFTWARE IS SUBJECT TO CHANGE WITHOUT NOTICE
0000 19     * AND SHOULD NOT BE CONSTRUED AS A COMMITMENT BY DIGITAL EQUIPMENT
0000 20     * CORPORATION.
0000 21     *
0000 22     * DIGITAL ASSUMES NO RESPONSIBILITY FOR THE USE OR RELIABILITY OF ITS
0000 23     * SOFTWARE ON EQUIPMENT WHICH IS NOT SUPPLIED BY DIGITAL.
0000 24     *
0000 25     *
0000 26     *****
0000 27
0000 28
0000 29     ++
0000 30
0000 31     FACILITY:
0000 32
0000 33     VAX/VMS TU58 DATA CARTRIDGE DRIVER
0000 34
0000 35
0000 36     ABSTRACT:
0000 37
0000 38     This module contains the tables and routines necessary to
0000 39     perform all device-dependent processing of an I/O request
0000 40     for the TU58 on a VAX/VMS operating system. This device
0000 41     operates using a RADIAL SERIAL PROTOCOL. For a spec of the
0000 42     TU58 and its RSP, see the 'TU58 DEctape II USER'S GUIDE',
0000 43     document # EK-0TU58-UG-001.
0000 44
0000 45     This driver is desinged to work with a DL-11 serial interface
0000 46     via the UBA registers, or as a console device via the internal
0000 47     processor registers.
0000 48
0000 49     AUTHOR:
0000 50
0000 51     S. T. Jeffreys          31-OCT-1979      (with thanks to Mark Grossman)
0000 52
0000 53     MODIFIED BY:
0000 54
0000 55     V03-007 RAS0300          Ron Schaefer          19-Jun-1984
0000 56     Add DEV$M_NNM characteristic to DECHAR2 so that these
0000 57     devices will have the 'node$' prefix.
```

```
0000 58 :
0000 59 :
0000 60 :
0000 61 :
0000 62 :
0000 63 :
0000 64 :
0000 65 :
0000 66 :
0000 67 :
0000 68 :
0000 69 :
0000 70 :
0000 71 :
0000 72 :
0000 73 :
0000 74 :
0000 75 :
0000 76 :
0000 77 :
0000 78 :
0000 79 :
0000 80 :
0000 81 :
0000 82 :
0000 83 :
0000 84 :
0000 85 :
0000 86 :
0000 87 :
0000 88 :
0000 89 :
0000 90 :
0000 91 :
0000 92 :
0000 93 :
0000 94 :
0000 95 :
0000 96 :
0000 97 :
0000 98 :
0000 99 :
0000 100 :
0000 101 :
0000 102 :
0000 103 :
0000 104 :
0000 105 :
0000 106 :
0000 107 :
0000 108 :
0000 109 :
0000 110 :
0000 111 :
0000 112 :
0000 113 :
0000 114 :
```

V03-006 PRD0044 Paul R DeStefano 10-Oct-1983
Made UNLOAD, AVAILABLE, and PACKACK legal functions and
added necessary code to handle these functions within
the driver.

V03-005 ROW0211 Ralph O. Weber 16-AUG-1983
Change device-dependent UCB definition base from UCB\$W_BCR+2
to UCB\$K_LCL_DISK_LENGTH.

V03-004 STJ3060 Steven T. Jeffreys 02-Mar-1983
- Do not use MRSP protocol when the TU58 is a console
device on 11/750 processors.
- Check the DD_V_USEMRSP bit instead of DD_V_MRSP when
deciding whether or not to use MRSP for this request.

V03-003 STJ48858 Steven T. Jeffreys 14-Sep-1982
- Add some sanity checks on the DATA packet byte count.

V03-002 KTA0100 Kerbey T. Altmann 07-Jun-1982
Add code to set UCB\$L_MEDIA_ID.

V03-001 STJ0260 Steven T. Jeffreys 15-Apr-1982
- A slight change for 11/730 initialization code.
Relax some of the sanity checking to allow for
variations between processors.

V02-008 STJ0232 Steven T. Jeffreys 02-Mar-1982
- Set the number of retries per request down to 4 (from 8).
- Modify the reset controller routine to always dump the
receiver buffer immediately after clearing the BRFAK.
- Modify dump recvr buf to return an error status if
the DONE bit never gets set.
- Modify snd pkt noint to return an error status if
the READY bit never gets set.

V02-007 STJ0107 Steven T. Jeffreys 19-Aug-1981
- Modified SND_PKT_NOINT to spin on the transmitter ready bit.
This is necessary for 11/750 console TU58s to init properly.
- Always return SSS_DATAOVERUN from GET_PACKET_C and GET_PACKET_U
so that in the event of an error, R0 will contain the correct
status code. For non-error conditions, R0 is ignored.

V02-006 TCM0001 Trudy C. Matthews 29-Jul-1981
Changed all '7ZZ's to '750's.

V02-005 JLV0025 Jake VanNoy 11-Jun-1981
Added DEFUNITS to DPT.

V02-004 STJ0027 Steven T. Jeffreys 24-Mar-1981
- Modify the driver so that the device dependent status info
is not returned in R1 (second longword of the IOSB).
Register R1 will be zeroed before completing the I/O.
- Return SSS_DATAOVERUN for data over run errors.
- Return SSS_PARITY for checksum errors.
- Alter error logging scheme to log all device errors.
Old scheme was to only log errors that aborted the request.

0000 115 :
0000 116 :
0000 117 :
0000 118 :
0000 119 :
0000 120 :
0000 121 :
0000 122 :
0000 123 :
0000 124 :
0000 125 :
0000 126 :
0000 127 :
0000 128 :--
0000 129

- Modify the controller error/reset routine so that it will return the original reason for the controller reset.
- Added support for multiple console TUS8s. (eg. (SA1, (SA2)
- Added support for MRSP.
- Optimized interrupt service routines to minimize interrupt latency and processor usage.

V02-003 ACG0179 Andrew C. Goldstein, 23-Jul-1980 18:17
Fix ACP class code in DPT

V02-002 STJ0001 Steve Jeffreys, 15-July-1980
Fix access violation on IOS_SEARCH requests.

```

0000 131          .SBTTL  EXTERNAL DEFINITIONS
0000 132          :
0000 133          : EXTERNAL SYMBOLS
0000 134          :
0000 135          $ADPDEF          ;Define adapter control block
0000 136          $CRBDEF          ;Define channel request block
0000 137          $DCDEF           ;Define device class
0000 138          $DDBDEF          ;Define device data block
0000 139          $DEVDEF          ;Define device characteristics
0000 140          $DPTDEF          ;Define driver prologue table
0000 141          $DYNDEF          ;Define data structure types
0000 142          $EMBDEF          ;Define error message buffer
0000 143          $IDBDEF          ;Define interrupt data block
0000 144          $IODEF           ;Define I/O function codes
0000 145          $IRPDEF          ;Define I/O request packet
0000 146          $PRDEF           ;Define processor registers
0000 147          $PTEDEF          ;Page table entry definitions
0000 148          $SSDEF           ;Define system status codes
0000 149          $UBADEF          ;Define unibus adapter
0000 150          $UCBDEF          ;Define unit control block
0000 151          $VECDEF          ;Define interrupt vector block

```

```
0000 153 .SBTTL LOCAL DEFINITIONS
0000 154 :
0000 155 : Local symbols
0000 156 :
0000 157 :
0000 158 :
0000 159 : TU58 register definitions
0000 160 :
0000 161 :
0000 162 $DEFINI DD ;Start of register definitions
0000 163 :
0000 164 $DEF DD_RCSR .BLKW 1 ;Receiver status register
0002 165 _VIELD DD_RCSR,0,<- ;Start of bit definitions
0002 166 <,8>,- ;Unused bits
0002 167 <RIE,,M>,- ;Receiver interrupt enable
0002 168 <RDONE,,M>,- ;Receiver done
0002 169 > ;
0002 170 $DEF DD_RBUF .BLKW 1 ;Receiver data buffer register
0004 171 _VIELD DD_RBUF,0,<- ;Start of bit definitions
0004 172 <,15>,- ;0-7 data , 8-14 unused
0004 173 <ERROR,,M>,- ;Composite error bit
0004 174 > ;
0004 175 $DEF DD_XCSR .BLKW 1 ;Transmitter status register
0006 176 _VIELD DD_XCSR,0,<- ;Start of bit definitions
0006 177 <BREAK,,M>,- ;Causes a framing error-break
0006 178 <,5>,- ;Unused
0006 179 <TIE,,M>,- ;Transmitter interrupt enable
0006 180 <TRDY,,M>,- ;Transmitter ready
0006 181 > ;
0006 182 $DEF DD_XBUF .BLKW 1 ;TRANSMITTER DATA BUFFER REGISTER
0008 183 :
0008 184 $DEFEND DD
0000 185 :
0000 186 :
0000 187 : Device function codes.
0000 188 :
00000001 0000 189 DD_CODE_DATACHECK = 1 ;Datacheck READ/WRITE modifier
00000002 0000 190 DD_CODE_READ = 2 ;Read request
00000003 0000 191 DD_CODE_WRITE = 3 ;Write request
00000005 0000 192 DD_CODE_SEARCH = 5 ;Search Request
00000007 0000 193 DD_CODE_DIAG = 7 ;Diagnostic request
0000000A 0000 194 DD_CODE_DETECT = 10 ;Detect TU58 type
0000 195 :
0000 196 : Radial serial protocol flags
0000 197 :
00000001 0000 198 DD_FLAG_DATA = 1 ;Data packet flag
00000002 0000 199 DD_FLAG_CNTL = 2 ;Command packet flag
00000004 0000 200 DD_FLAG_INIT = 4 ;Initialize controller flag
00000010 0000 201 DD_FLAG_CONT = 16 ;Continue flag
00000013 0000 202 DD_FLAG_XOFF = 19 ;Suspend device action flag
00000010 0000 203 ACK_CHAR = DD_FLAG_CONT ;ACK character for MRSP
00000003 0000 204 MRSP_V_SWITCH = 3 ;Switch vield for MRSP
00000008 0000 205 MRSP_M_SWITCH = 8 ;Switch mask for MRSP
00000A02 0000 206 CMD_PKT_HDR = ^X0A02 ;Command packet header switch
000A0A02 0000 207 DETECT_PKT_HDR = ^X000A0A02 ;Special command packet header
00000A0C 0000 208 DETECT_PKT_CHKSM = ^X0A0C ;Special command packet checksum
00000404 0000 209 TWO_INITS = ^X0404 ;Two INIT characters
```

```
0000 211 ;
0000 212 ; Device dependent status codes returned in the END PACKET.
0000 213 ;
00000000 0000 214 DD_STS_NORMAL = 0 ;Normal success
00000001 0000 215 DD_STS_RETRY = 1 ;Success but with retries
FFFFFFFF 0000 216 DD_STS_BADDIAG = -1 ;Failed self test (diagnostics)
FFFFFFFFE 0000 217 DD_STS_PARTOP = -2 ;Partial operation (end of tape)
FFFFFFFF8 0000 218 DD_STS_BADUNIT = -8 ;Bad unit #
FFFFFFFF7 0000 219 DD_STS_NOCART = -9 ;No cartridge
FFFFFFFF5 0000 220 DD_STS_WRTLCK = -11 ;Write locked
FFFFFFEF 0000 221 DD_STS_DATACHK = -17 ;Data check error
FFFFFFE0 0000 222 DD_STS_BLKNF = -32 ;Seek error (block not found)
FFFFFFDF 0000 223 DD_STS_MTRSTOP = -33 ;Motor stopped
FFFFFFD0 0000 224 DD_STS_BADOPCD = -48 ;Bad op code
FFFFFFC9 0000 225 DD_STS_BADRCD = -55 ;Bad record #
0000 226 ;
0000 227 ; The remainder of the status codes are internal
0000 228 ; to this driver, and are used only for debugging.
0000 229 ;
FFFFFFC7 0000 230 DD_STS_BADINIT = -57 ;Failed init sequence
FFFFFFC6 0000 231 DD_STS_BADCKSM = -58 ;Failed checksum comparison
FFFFFFC5 0000 232 DD_STS_DATAOVR = -59 ;Data over-run
0000 233 ;
0000 234 ; Define various and sundry symbols.
0000 235 ;
0000000E 0000 236 DD_CP_LEN = 14 ;Command packet buffer length in bytes
0000000E 0000 237 DD_EP_LEN = 14 ;End packet buffer length in bytes
00000004 0000 238 DD_NUM_REGS = 4 ;Number of device registers
0000002C 0000 239 DD_ERRBUF_LEN = <<DD_NUM_REGS * 4> + DD_CP_LEN + DD_EP_LEN> ;Length of error buffer in longwords
0000000B 0000 240 DD_ERRBUF_LEN_L = 11 ;Length of error buffer in longwords
0000000A 0000 241 DD_CP_BCNT = 10 ;Command packet byte count
00000002 0000 242 DD_CHRSM_LEN = 2 ;Packet checksum length in bytes
00000080 0000 243 DD_MAX_PKT_BCNT = 128 ;Maximum data packet byte count
00000001 0000 244 DD_DPBCNT = 1 ;Offset to data packet byte count
00000002 0000 245 DD_DATA = 2 ;Offset to data w/i data packet
00000084 0000 246 DD_DPBUF_LEN = <DD_MAX_PKT_BCNT + 4> ;Data packet buffer length
00000034 0000 247 LONG_WAIT = 52 ;# of seconds before read timeout
00000002 0000 248 SHORT_WAIT = 2 ;# of seconds to wait after first byte read
00000002 0000 249 WRITE_WAIT = 2 ;# of seconds before write timeout
00000017 0000 250 HIGH_DIPL = 23 ;Special DIPL for COMET
00004E20 0000 251 MAXCHRTIM = 20000 ;Maximum character time, in 10 u-sec
0000 252 ; units, assuming a 50 baud line.
0000 253 ;
0000 254 ; Define the bits for device dependent status word in the UCB.
0000 255 ; The field that contains these bits is UCBSW_TU58STS.
0000 256 ;
0000 257 ; _VIELD DD,0,<- ;Start of bit definitions
0000 258 <CONSOLE,,M>,- ;Console device
0000 259 <PASS1,,M>,- ;Determines where to call buffer routines
0000 260 <MRSP,,M>,- ;This TU58 speaks MRSP
0000 261 <USEMRSP,,M>,- ;Use MRSP for this operation
0000 262 > ;End of bit definitions
```

```
0000 264 :  
0000 265 : Define extensions to UCB  
0000 266 :  
0000 267 $DEFINI UCB ;Start of UCB extensions  
0000 268 :  
000000CC 0000 269 .=UCBSK_LCL_DISK_LENGTH ;Begin definitions at end of UCB  
00CC 270 $DEF UCBSL_DD_BUFWIN .BLKL 1 ;Window to user's buffer  
00D0 271 $DEF UCBSL_DD_DPTR .BLKL 1 ;Pointer to data packet buffer  
00D4 272 $DEF UCBSL_DD_MSGPKT .BLKL 1 ;Current message packet address  
00D8 273 $DEF UCBSW_DD_MSGLEN .BLKW 1 ;Current message packet length  
00DA 274 :  
00DA 275 : Define buffer for device registers.  
00DA 276 :  
00DA 277 $DEF UCBSK_DD_REGBUF ;Register buffer address  
00DA 278 $DEF UCBSW_DD_XCSR .BLKW 1 ;Transmitter CSR  
00DC 279 $DEF UCBSW_DD_XBUF .BLKW 1 ;Transmitter buffer  
00DE 280 $DEF UCBSW_DD_RCSR .BLKW 1 ;Receiver CSR  
00E0 281 $DEF UCBSW_DD_RBUF .BLKW 1 ;Receiver buffer  
00E2 282 :  
00E2 283 : Define the Command Packet buffer.  
00E2 284 :  
00E2 285 $DEF UCBSK_DD_CPADDR ;Command packet buffer address  
00E2 286 $DEF UCBSB_DD_CPFLAG .BLKB 1 ;Command packet flag byte  
00E3 287 $DEF UCBSB_DD_CPBCNT .BLKB 1 ;Command packet byte count  
00E4 288 $DEF UCBSB_DD_OPCODE .BLKB 1 ;Op code  
00E5 289 $DEF UCBSB_DD_OPMOD .BLKB 1 ;Op code modifier  
00E6 290 $DEF UCBSB_DD_UNIT .BLKB 1 ;Unit number  
00E7 291 $DEF UCBSB_DD_SWITCH .BLKB 1 ;Switches  
00E8 292 $DEF UCBSB_DD_SEQL .BLKB 1 ;Sequence number - low byte  
00E9 293 $DEF UCBSB_DD_SEQH .BLKB 1 ;Sequence number - high byte  
00EA 294 $DEF UCBSB_DD_BCNTL .BLKB 1 ;Byte count - low byte  
00EB 295 $DEF UCBSB_DD_BCNTH .BLKB 1 ;Byte count - high byte  
00EC 296 $DEF UCBSB_DD_BLK_L .BLKB 1 ;Block number - low byte  
00ED 297 $DEF UCBSB_DD_BLK_H .BLKB 1 ;Block number - high byte  
00EE 298 $DEF UCBSW_DD_CPCKSM .BLKW 1 ;Command packet checksum  
00F0 299 :  
00F0 300 : Define the End Packet buffer  
00F0 301 :  
00F0 302 $DEF UCBSK_DD_EPADDR ;End packet buffer address  
00F0 303 $DEF UCBSB_DD_EPFLAG .BLKB 1 ;End packet flag  
00F1 304 $DEF UCBSB_DD_EPBCNT .BLKB 1 ;Packet byte count  
00F2 305 $DEF UCBSB_DD_EPCODE .BLKB 1 ;Op code  
00F3 306 $DEF UCBSB_DD_EPSTS .BLKB 1 ;Success code  
00F4 307 $DEF UCBSB_DD_EPUNIT .BLKB 4 ;Unit # (next 3 bytes not used)  
00F8 308 $DEF UCBSW_DD_ABCNT .BLKW 1 ;Actual byte count (bytes transfered)  
00FA 309 $DEF UCBSW_DD_SMSTS .BLKW 1 ;Summary status (more status info)  
00FC 310 $DEF UCBSW_DD_EPCKSM .BLKW 1 ;Packet checksum  
00FE 311 :  
00FE 312 $DEF UCBSK_DD_UCBLEN ;Last loc. in UCB  
00FE 313 $DEFEND UCB  
0000 314 :  
0000 315 :  
0000 316 : The following are psuedonyms for existing but unused fields in the UCB.  
0000 317 :  
000000CA 0000 318 UCBSW_TU58STS = UCBSB_OFFNDX ;Device specific status  
0000 319 ;This field also uses UCBSB_OFFRTC  
0000 320 :
```

DDDRIVER
V04-000

- TUS8 DC100 TAPE CARTRIDGE DRIVER¹ 1
LOCAL DEFINITIONS

16-SEP-1984 00:19:23 VAX/VMS Macro V04-00
5-SEP-1984 00:12:11 [DRIVER.SRC]DDDRIVER.MAR;1

Page 8
(1)

DD
VC

0000 321 ; Note that the following fields in the UCB are currently not
0000 322 ; used by the TUS8 driver, and may be used as the need arises.
0000 323 ;
0000 324 : UCBSB_FEX
0000 325 : UCBSB_CEX
0000 326 : UCBSx-xxx (unused, WORD sized field contiguous with UCBSB_CEX)
0000 327 : UCBSW_EC1
0000 328 : UCBSW_EC2

```
0000 330      .SBTTL  LOCAL MACRO DEFINITIONS
0000 331      :
0000 332      :      LOCAL MACRO DEFINITIONS
0000 333      :
0000 334      :
0000 335      :
0000 336      : GET_PACKET      - Get a packet of data from the TU58
0000 337      :
0000 338      .MACRO  GET_PACKET      ?L1,?L2
0000 339      BBC      #DD V_CONSOLE,-      ;Branch if not a console device
0000 340      UCB$W-TU58STS(R5),L1      :
0000 341      BSBW      GET_PACKET_C      ;Get packet (console)
0000 342      BRB      L2      ;Rejoin common code
0000 343      L1:      BSBW      GET_PACKET_U      ;Get packet (unibus)
0000 344      L2:
0000 345      .ENDM  GET_PACKET
0000 346      :
0000 347      :
0000 348      : SEND_PACKET      - Send a packet of data to the TU58
0000 349      :
0000 350      .MACRO  SEND_PACKET      ?L1,?L2
0000 351      BBC      #DD V_CONSOLE,-      ;Branch if not a console device
0000 352      UCB$W-TU58STS(R5),L1      :
0000 353      BSBW      SEND_PACKET_C      ;Send packet (console)
0000 354      BRB      L2      ;Rejoin common code
0000 355      L1:      BSBW      SEND_PACKET_U      ;Send packet (unibus)
0000 356      L2:
0000 357      .ENDM  SEND_PACKET
0000 358      :
0000 359      :
0000 360      : GET_BYTE      - Get a byte of data from the device.
0000 361      :
0000 362      :
0000 363      .MACRO  GET_BYTE
0000 364      MOVAB      UCB$B_SPR(R5),-      ;Get buffer address
0000 365      UCB$L-DD_MSGPKT(R5)      :
0000 366      MOVW      #1,UCB$W-DD_MSGLEN(R5) ;Get buffer length
0000 367      GET_PACKET      ;Get the data
0000 368      .ENDM  GET_BYTE
0000 369      :
0000 370      :
0000 371      : SEND_BYTE      - Send a byte of data to the device.
0000 372      :
0000 373      .MACRO  SEND_BYTE
0000 374      MOVAB      UCB$B_SPR(R5),-      ;Get buffer address
0000 375      UCB$L-DD_MSGPKT(R5)      :
0000 376      MOVW      #1,UCB$W-DD_MSGLEN(R5) ;Get buffer length
0000 377      SEND_PACKET      ;Send data
0000 378      .ENDM  SEND_BYTE
0000 379      :
0000 380      :
0000 381      :
0000 382      : MOVTOUSER
0000 383      :
0000 384      : Move a string of data to the user's buffer.
0000 385      : Assume all inputs have been set up.
0000 386      : The different entry points are needed to avoid problems
```

```
0000 387 ; with page aligned user buffers.
0000 388 ;
0000 389 .MACRO MOVTOUSER ?L1,?L2
0000 390 BBSC #DD V_PASS1,- ;Is this the first data transfer?
0000 391 UCB$W-TU58STS(R5),L1 ;Branch if yes
0000 392 MOVL UCB$L-DD_BUFWIN(R5),R0 ;Get window into user's buffer
0000 393 JSB G^IOC$MOVTOUSER2 ;Move data
0000 394 BRB L2 ;Rejoin common code
0000 395 L1: JSB G^IOC$MOVTOUSER ;Move data
0000 396 L2: MOVL R0,UCB$L-DD_BUFWIN(R5) ;Save new window
0000 397 .ENDM MOVTOUSER
0000 398
0000 399
0000 400 ;
0000 401 ; MOVFROMUSER
0000 402 ;
0000 403 ; Move a string of data from the user's buffer.
0000 404 ; Assume all inputs have been set up.
0000 405 ; The different entry points are needed to avoid problems
0000 406 ; with page aligned user buffers.
0000 407 ;
0000 408 .MACRO MOVFROMUSER ?L1,?L2
0000 409 BBSC #DD V_PASS1,- ;Is this the first data transfer?
0000 410 UCB$W-TU58STS(R5),L1 ;Branch if yes
0000 411 MOVL UCB$L-DD_BUFWIN(R5),R0 ;Get window into user's buffer
0000 412 JSB G^IOC$MOVFRUSER2 ;Move data
0000 413 BRB L2 ;Rejoin common code
0000 414 L1: JSB G^IOC$MOVFRUSER ;Move data
0000 415 L2: MOVL R0,UCB$L-DD_BUFWIN(R5) ;Save new window
0000 416 .ENDM MOVFROMUSER
```

```
0000 418 .SBTTL DRIVER PROLOGUE TABLE
0000 419 :
0000 420 : DRIVER PROLOGUE TABLE
0000 421 :
0000 422 : The DPT describes driver parameters and I/O database fields
0000 423 : that are initialized during driver LOADING and RELOADING.
0000 424 :
0000 425 DPTAB - ;DPT creation macro
0000 426 END=DD_END,- ;End of driver
0000 427 ADAPTER=UBA,- ;Adapter type = UNIBUS
0000 428 FLAGS=DPTSM_SVP,- ;System page table entry required
0000 429 UCBSIZE=<UCBSK_DD_UCBLEN>,- ;Length of UCB
0000 430 NAME=DDDRIVER,- ;Driver name
0000 431 DEFUNITS=2 ;Number of units to autoconfigure.
0038 432
0038 433 DPT_STORE INIT ;START CONTROL BLOCK INIT VALUES
0038 434 DPT_STORE DDB,DDB$$_ACPD,L,<^A\F11\> ;Default ACP name
003F 435 DPT_STORE DDB,DDB$$_ACPD+3,B,DDB$$_TAPE ;ACP class
0043 436 DPT_STORE UCB,UCB$$_FIPL,B,8 ;Fork IPL
0047 437
0047 438 DPT_STORE UCB,UCB$$_DEVCHAR,L,- ;DEVICE CHARACTERISTICS
0047 439 <DEVSM_FOD- ; - File oriented
0047 440 !DEVSM_DIR- ; - Directory structured
0047 441 !DEVSM_AVL- ; - Available
0047 442 !DEVSM_ELG- ; - Error logging
0047 443 !DEVSM_SHR- ; - Shareable
0047 444 !DEVSM_IDV- ; - Input device
0047 445 !DEVSM_ODV- ; - Output device
0047 446 !DEVSM_RND> ; - Random access
004E 447 DPT_STORE UCB,UCB$$_DEVCHAR2,L,- ; DEVICE CHARACTERISTICS
004E 448 <DEVSM_NNM> ; Prefix name with 'node$'
0055 449
0055 450 DPT_STORE UCB,UCB$$_DEVCLASS,B,DC$$_DISK ;Device class
0059 451 DPT_STORE UCB,UCB$$_DEVTYPE,B,DT$$_TUS8 ;Device type
005D 452 DPT_STORE UCB,UCB$$_DEVBUFSIZ,W,ST2 ;Default buffer size
0062 453 DPT_STORE UCB,UCB$$_SECTORS,B,128 ;Number of sectors/track
0066 454 DPT_STORE UCB,UCB$$_TRACKS,B,4 ;Number of tracks/cylinder
006A 455 DPT_STORE UCB,UCB$$_CYLINDERS,W,1 ;Number of cylinders
006F 456 DPT_STORE UCB,UCB$$_DIPL,B,20 ;Device IPL
0073 457 DPT_STORE UCB,UCB$$_ERTMAX,B,4 ;Maximum error retry count
0077 458 DPT_STORE UCB,UCB$$_MAXBLOCK,L,512 ;Maximum # of blocks
007E 459 DPT_STORE UCB,UCB$$_MEDIA_ID,-
007E 460 L,<^X2129503A> ;Media ident 'DD TUS8'
0085 461 DPT_STORE REINIT ;START CONTROL BLOCK RE-INIT VALUES
0085 462 DPT_STORE CRB,CRB$$_INTD+4,D,DD_INT ;Interrupt service routine address
008A 463 DPT_STORE CRB,CRB$$_INTD2+4,D,DD_INT ;Interrupt service routine address
008F 464 DPT_STORE CRB,- ;Unit init
008F 465 CRB$$_INTD+VEC$$_UNITINIT,D,-
008F 466 DD_UNIT_NIT
0094 467 DPT_STORE DDB,DDB$$_DDT,D,DD$$_DDT ;DDT address
0099 468
0099 469 DPT_STORE END ;End of prologue table
0000 470
```

```

0000 472      .SBTTL DRIVER DISPATCH TABLE
0000 473      :
0000 474      : DRIVER DISPATCH TABLE
0000 475      :
0000 476      : The DDT list entry points for the driver subroutines which are
0000 477      : called by the operating system.
0000 478      :
0000 479      :
0000 480      JDTAB - ;DDT creation macro
0000 481      DEVNAM=DD,- ;Generic device name
0000 482      START=DD STARTIO,- ;STARTIO routine address
0000 483      UNSOLIC=0,- ;Unsolicited interrupt handler
0000 484      FUNCTB=DD FUNCTABLE,- ;FDT address
0000 485      CANCEL=0,- ;CANCEL I/O handler
0000 486      REGDMP=DD REGDUMP,- ;Register dump routine address
0000 487      DIAGBF=<DD_ERRBUF_LEN+<<1+3+5>*4>>,- ;Byte size of diab buffer
0000 488      ERLGBF=<DD_ERRBUF_LEN+<1*4>+<EMBSL_DV_REGSAB>> ;Byte size of
0038 489      ;errorlog buffer
0038 490

```

```
0038 492 .SBTTL FUNCTION DECISION TABLE
0038 493 :
0038 494 : FUNCTION DECISION TABLE
0038 495 :
0038 496 : The FDT lists valid function codes, specifies which codes
0038 497 : are buffered, and designates subroutines to perform I/O
0038 498 : preprocessing for particular functions.
0038 499 :
0038 500
0038 501 DD_FUNCTABLE:
0038 502
0038 503 FUNCTAB,-
0038 504 <DIAGNOSE,- ;LIST LEGAL FUNCTIONS
0038 505 SEARCH,- ;RUN INTERNAL DIAGNOSTICS
0038 506 SENSECHAR,- ;SEARCH FOR BLOCK
0038 507 SETCHAR,- ;SENSE CHARACTERISTICS
0038 508 SENSEMODE,- ;SET CHARACTERISTICS
0038 509 SETMODE,- ;SENSE MODE
0038 510 READLBLK,- ;SET MODE
0038 511 WRITELBLK,- ;READ LOGICAL BLOCK
0038 512 READPBLK,- ;WRITE LOGICAL BLOCK
0038 513 WRITEPBLK,- ;READ PHYSICAL BLOCK
0038 514 READVBLK,- ;WRITE PHYSICAL BLOCK
0038 515 WRITEVBLK,- ;READ VIRTUAL BLOCK
0038 516 ACCESS,- ;WRITE VIRTUAL BLOCK
0038 517 ACPCONTROL,- ;ACCESS FILE / FIND DIRECTORY ENTRY
0038 518 CREATE,- ;ACP CONTROL FUNCTION
0038 519 DEACCESS,- ;CREATE FILE AND /OR DIRECTORY ENTRY
0038 520 DELETE,- ;DEACCESS FILE
0038 521 MODIFY,- ;DELETE FILE AND / OR DIRECTORY ENTRY
0038 522 MOUNT,- ;MODIFY FILE ATTRIBUTES
0038 523 UNLOAD,- ;MOUNT VOLUME
0038 524 AVAILABLE,- ;UNLOAD VOLUME
0038 525 PACKACK,- ;AVAILABLE
0038 526 > ;PACK ACKNOWLEDGE
0040 527
0040 528 FUNCTAB,- ;BUFFERED FUNCTIONS
0040 529 <SENSECHAR,- ;SENSE CHARACTERISTICS
0040 530 SETCHAR,- ;SET CHARACTERISTICS
0040 531 SENSEMODE,- ;SENSE MODE
0040 532 SETMODE,- ;SET MODE
0040 533 ACCESS,- ;ACCESS FILE / FIND DIRECTORY ENTRY
0040 534 ACPCONTROL,- ;ACP CONTROL FUNCTION
0040 535 CREATE,- ;CREATE FILE AND /OR DIRECTORY ENTRY
0040 536 DEACCESS,- ;DEACCESS FILE
0040 537 DELETE,- ;DELETE FILE AND / OR DIRECTORY ENTRY
0040 538 MODIFY,- ;MODIFY FILE ATTRIBUTES
0040 539 MOUNT,- ;MOUNT VOLUME
0040 540 UNLOAD,- ;UNLOAD VOLUME
0040 541 AVAILABLE,- ;AVAILABLE
0040 542 PACKACK,- ;PACK ACKNOWLEDGE
0040 543 >
0048 544 FUNCTAB +ACPSREADBLK,- ;READ FUNCTIONS
0048 545 <READLBLK,-
0048 546 READPBLK,-
0048 547 READVBLK,-
0048 548 >
```

0054	549	FUNCTAB	+ACPSWRITEBLK,-	;WRITE FUNCTIONS
0054	550		<WRITELBLK,-	
0054	551		WRITEPBLK,-	
0054	552		WRITEVBLK,-	
0054	553		>	
0060	554	FUNCTAB	+ACPSACCESS,-	
0060	555		<ACCESS,-	
0060	556		CREATE-	
0060	557		>	
006C	558	FUNCTAB	+ACPSDEACCESS,-	
006C	559		<DEACCESS-	
006C	560		>	
0078	561	FUNCTAB	+ACPSMODIFY,-	
0078	562		<ACPCONTROL,-	
0078	563		DELETE,-	
0078	564		MODIFY-	
0078	565		>	
0084	566	FUNCTAB	+EXESLCLDSKVALID,-	;LOCAL DISK VALID FUNCTIONS
0084	567		<UNLOAD,-	;UNLOAD VOLUME
0084	568		AVAILABLE,-	;AVAILABLE
0084	569		PACKACK,-	;PACK ACKNOWLEDGE
0084	570		>	
0090	571	FUNCTAB	+EXESONEPARM,-	;ONE PARAMETER FUNCTIONS
0090	572		<SEARCH,-	
0090	573		>	
009C	574	FUNCTAB	+EXESZEROPARM,-	;ZERO PARAMETER FUNCTIONS
009C	575		<DIAGNOSE,-	;DIAGNOSE THE DRIVE
009C	576		>	
00A8	577	FUNCTAB	+ACPSMOUNT,-	
00A8	578		<MOUNT-	
00A8	579		>	
00B4	580	FUNCTAB	+EXESSENSEMODE,-	
00B4	581		<SENSECHAR,-	
00B4	582		SENSEMODE-	
00B4	583		>	
00C0	584	FUNCTAB	+EXESSETCHAR,-	
00C0	585		<SETCHAR,-	
00C0	586		SETMODE-	
00C0	587		>	
00CC	588			

```
00CC 590      .SBTTL  TUS8 UNIT INITIALIZATION
00CC 591      :++
00CC 592      DD_UNIT_INIT - TUS8 TAPE CARTRIDGE UNIT INITIALIZATION
00CC 593      :
00CC 594      : The operating system calls this routine at system startup,
00CC 595      : during driver loading and during recovery from power failure.
00CC 596      :
00CC 597      INPUTS:
00CC 598      :
00CC 599      :         R4 = ADDRESS OF CSR
00CC 600      :         R5 = ADDRESS OF UNIT CONTROL BLOCK
00CC 601      :
00CC 602      : All interrupts are locked out.
00CC 603      :
00CC 604      OUTPUTS:
00CC 605      :
00CC 606      : Allocate a data packet buffer out of nonpaged pool, if the buffer
00CC 607      : has not already been allocated. This is done to reduce the size
00CC 608      : of the UCB. If the buffer cannot be allocated, exit immediately.
00CC 609      : In addition to the buffer itself, a 12 byte header must be allocated,
00CC 610      : and certain fields be initilaized so that the buffer can be self-
00CC 611      : identifying.
00CC 612      :
00CC 613      : The unit status is set to online and a determination is made
00CC 614      : as to whether the unit interfaces via unibus adapter registers(UBA)
00CC 615      : or internal processor registers(IPR). If the unit uses IPR's, then
00CC 616      : it is a console device. The device is a console device if
00CC 617      : the CSR address is not a system address. All system addresses
00CC 618      : have bit 31 = 1, which makes them appear negative.
00CC 619      :
00CC 620      Side Effects:
00CC 621      :
00CC 622      : If the processor type is unknown, or the sector buffer could not
00CC 623      : be allocated, mark the device (UCB) offline to prevent it use.
00CC 624      :--
00CC 625 DD_UNIT_INIT:                                ;TUS8 controller intialization
00CC 626 :
00CC 627 : Allocate the buffer if it has not been allocated yet.
00CC 628 :
00CA C5      B4 00CC 629      CLRW      UCB$W_TUS8STS(R5)      ;Reset device status flags
00CC 630      BBBS      #UCB$V_ONLINE,-                      ;Set device online
00 64 A5      E3 00D0 631      UCB$W_STS(R5),10$          ;
00D0 C5      D5 00D2 631      UCB$W_STS(R5),10$          ;
00D0 C5      D5 00D5 632 10$: TSTL      UCB$L_DD_DPTR(R5)    ;Is pointer to buffer nonzero?
00D0 C5      D5 00D9 633      BNEQ      20$                ;Branch if yes
00D0 C5      D5 00DB 634      PUSHL     R4                  ;Save R4
54 00000000'GF DE 00DD 635      MOVAL     G^EXE$GL_NONPAGED,R4 ;Put address of nonpaged pool
00E4 636      :list head in R4
00E4 637      PUSHL     (R4)                                ;Save IPL in pool list head
00E6 638      MFPR      #PR$_IPL,(R4)                      ;Save IPL in pool list head
51 64 12      DB 00F9 639      MOVZBL    #<DD-DBBUF_LEN+12>,R1 ;Set buffer length in R1
00000000'GF 16 00ED 640      JSB       G^EXE$ALONONPAGED    ;Allocate data packet buffer
00E4 641      POPL      (R4)                                ;Restore IPL in list head
00E6 642      POPL      R4                                  ;Restore R4
00E9 643      BLBC      R0,13$                              ;Branch if error
08 A2 51      B0 00FC 644      MOVW      R1,8(R2)           ;Put size into buffer header
0A A2 13      90 0100 645      MOVB      #DYN$C_BUF10,10(R2) ;Put type into buffer header
00D0 C5      52 0C C1 0104 646      ADDL3     #12,R2,-        ;Save pointer to start of actual
```

```
010A 647 UCB$LD_DPTR(R5) ;data packet buffer.
010A 648 :
010A 649 :
010A 650 : Check the CSR address to determine if this is a console or unibus
010A 651 : TUSB. Unibus TUSBs will have a CSR address that is a system
010A 652 : address, and the number will appear negative. Console TUSBs will
010A 653 : have a CSR address that is actually a processor internal register
010A 654 : number, and will appear to be a positive number.
54 D5 010A 655 20$: TSTL R4 ;Test CSR address
15 13 010C 656 BEQL 13$ ;Sanity check
23 19 010E 657 BLSS 50$ ;Branch if unibus TUSB
0110 658 :
0110 659 : The device is a console TUSB. Mark it as such.
0110 660 : Determine the CPU type and set the device IPL field
0110 661 : in the UCB accordingly.
0110 662 :
50 00000000'GF 90 0110 663 MOVBL G^EXESGB_CPUYPE,R0 ;Get CPU type code
OA 15 0117 664 BLEQ 13$ ;Sanity check
50 03 91 0119 665 CMPBL #PR$_SID_TYP730,R0 ;Is this a 730 cpu?
OF 13 011C 666 BEQL 40$ ;Branch if yes
50 02 91 011E 667 CMPBL #PR$_SID_TYP750,R0 ;Is this a 750 cpu?
06 13 0121 668 BEQL 30$ ;Branch if yes
04 E4 0123 669 13$: BBSC #UCB$V_ONLINE,- ;Set device offline
00 64 A5 0125 670 UCB$W_STS(R5),14$ ;
05 0128 671 14$: RSB ;Just in case
17 90 0129 672 30$: MOVBL #HIGH_DIPL,- ;Set high device IPL for 750 cpu
5E A5 012B 673 UCB$B_DIPL(R5) ;
00 00 012D 674 40$: BBSS #DD_V_CONSOLE,- ; Mark this unit as a console device
00 00CA C5 012F 675 UCB$W_TUSBSTS(R5),50$ ;
01 10 0133 676 50$: BSBB INIT_ONIT ;Do second half of unit initialization
0135 677 : BLBC R0,13$ ;Branch if error
05 0135 678 RSB ;Return
```

```
0136 680 .SBTTL INIT_UNIT
0136 681 :++
0136 682 : INIT_UNIT
0136 683 :
0136 684 : This routine is the second half of the TU58 unit initialization
0136 685 : routine. This routine will initialize the controller and determine
0136 686 : if the controller speaks MRSP. The algorithm for determining the
0136 687 : TU58 controller type is given below.
0136 688 :
0136 689 : Determining the TU58 controller type:
0136 690 :
0136 691 : Initialize the controller, and then send it a command packet with
0136 692 : the flow control bit set (MRSP_M_SWITCH in the SWITCH field of the
0136 693 : command packet), and get the first byte of the controller's response.
0136 694 : If the controller speaks MRSP, the response will be 02 (which is the
0136 695 : first byte of an end packet). If the controller does not speak MRSP,
0136 696 : then the first byte will be 01 (first byte of a data packet). Note
0136 697 : that a data overrun condition will also indicate that the controller
0136 698 : does not speak MRSP. If an overrun condition did not occur, and the
0136 699 : response was not 01 or 02, then assume that there is a hard controller
0136 700 : error, and exit with the appropriate error status. After getting the
0136 701 : response, ignore the rest of the data sent by the TU58 and reinitialize
0136 702 : the controller.
0136 703 :
0136 704 : Input:
0136 705 : IPL = IPL$ POWER
0136 706 : R0 .. R3 = scratch
0136 707 : R4 = CSR address
0136 708 : R5 = UCB address
0136 709 :
0136 710 : Output:
0136 711 : R0 is even if error, odd if success
0136 712 : --
0136 713 :
0136 714 : INIT_UNIT:
0136 715 : BSBW RESET CONTROLLER ;Second half of unit initialization
0136 716 : BLBC R0,13$ ;Initialize the controller
0136 717 : ;Branch if error
0136 718 :
0136 719 : Build the special command packet used to detect the controller type.
0136 720 : Note that since the only variables in the command packet will be the
0136 721 : device unit number (which will also cause the checksum to vary) the
0136 722 : command packet can be built quickly, and the checksum computed easily.
0136 723 :
0136 724 : MOVAL UCBSK DD CPADDR(R5),R2 ;Get address of command packet buffer
0136 725 : MOVL #DTECT_PRT_HDR,(R2)+ ;Set FLAG, PKT_BCNT, OPCODE, and OPMOD
0136 726 : MOVZWL UCBSW ONIT(R5),R0 ;Get device unit #
0136 727 : BBSS #<MRSP_V_SWITCH+8>,R0,10$ ;Set MRSP switch bit to prevent data
0136 728 : ;overruns on 730 processors.
0136 729 : 10$: BBC #DD_V_CONSOLE,- ;Branch if not console device
0136 730 : UCBSW_TU58STS(R5),20$ ;
0136 731 : 20$: DECW R0 ;Decrement the unit #
0136 732 : MOVL R0,(R2)+ ;Set the UNIT, SWITCH, and SEQUENCE #
0136 733 : CLRL (R2)+ ;Clear TRANSFER COUNT and BLOCK #
0136 734 : ADDW3 #DTECT_PKT_CHKSM,R0,(R2);Compute and set the CHECKSUM
0136 735 :
0136 736 : Send the command packet to the controller.
```

047F	30				
68 50	E9				
		DE			
		D0			
		3C			
		E2			
		E1			
		B7			
		D0			
		D4			
		A1			
82	52	00E2	C5		
	000A0A02	8F			
	50	54	A5		
	00 50	0B			
		00			
	02 00CA	C5			
		50			
	82	50			
		82			
62	50	0A0C	8F		

```
52 00D4 C5 9E 0163 737 MOVAB UCBSL_DD_MSGPKT(R5),R2 ;Get address of packet pointer
82 00E2 C5 DE 0168 738 MOVAL UCBSK_DD_CPADDR(R5),(R2) ;Get command packet address
    62 0E B0 016D 739 MOVW #DD_CP_LEN,(R2) ;Get command packet length
    40 10 0170 740 BSBB SND_PKT_NOINT ;Send command packet
    2F 50 E9 0172 741 BLBC R0,T3$ ;Branch if error
        0175 742 ;
        0175 743 ;
        0175 744 ;
        0175 745 ;
        0175 746 ;
    009E 30 0175 747 BSBB DUMP_RECVR_BUF ;Get controller response
    29 50 E9 0178 748 BLBC R0,T3$ ;Branch if error
    1F 51 0F E0 017B 749 BBS #DD_RBUF_V_ERROR,R1,30$ ;Branch if data overrun
    51 01 91 017F 750 CMPB #DD_FLAG_DATA,R1 ;Was it a data packet flag?
        1A 13 0182 751 BEQL 30$ ;Branch if equal
    51 02 91 0184 752 CMPB #DD_FLAG_CNTL,R1 ;Was it a command packet flag?
        1B 12 0187 753 BNEQ 13$ ;Branch if not
    00000000 GF 91 0189 754 CMPB G^EXESGB_CPUTYPE,- ;Is this a 750 cpu?
        02 018F 755 #PR$_SID_TYP750
        06 12 0190 756 BNEQ 25$ ;Branch if not
        00 E0 0192 757 BBS #DD_V_CONSOLE,- ;Branch if 11/750 console device
    06 00CA C5 0194 758 UCBSW_TU58STS(R5),30$ ;(ie. do not set the MRSP bit)
        02 E2 0198 759 25$: BBSS #DD_V_MRSP,- ;Set MRSP bit
    00 00CA C5 019A 760 UCBSW_TU58STS(R5),30$
        04 17 30 019E 761 30$: BSBW RESET_CONTROLLER ;Ignore the rest of the response
        0D 50 E8 01A1 762 BLBS R0,40$ ;Branch if success
        01A4 763 ;
        01A4 764 ;
        01A4 765 ;
        51 D4 01A4 766 13$: CLRL R1 ;
        06F1 30 01A6 767 BSBW RCSR ;Clear receiver CSR
        06DF 30 01A9 768 BSBW SCSR ;Clear transmitter CSR
    50 0054 8F B0 01AC 769 MOVW #SS$_CTRLERR,R0 ;Set error status
        05 01B1 770 40$: RSB ;Return
```



```
0216 823 .SBTTL DUMP_RECVR_BUF
0216 824 :++
0216 825 : DUMP_RECVR_BUF
0216 826 :
0216 827 : Dump the contents of the receiver buffer to R1.
0216 828 : This routine will wait (via a delay loop) for
0216 829 : approximately 1 character time before giving up.
0216 830 : Note that the receiver buffer is dumped no matter what.
0216 831 : This routine executes at IPL equal to IPL$ POWER.
0216 832 :
0216 833 : Input: R4 = CSR address
0216 834 : R5 = UCB address
0216 835 :
0216 836 : Output: R1 = contents of receiver buffer
0216 837 : R0 is destroyed.
0216 838 :--
0216 839
0216 840 DUMP_RECVR_BUF: ;Dump receiver buffer
0216 841 MUEL3 #MAXCHRTIM,G^EXE$GL_TENUSEC,R0;Calc wait interval
0222 842 BBC #DD V_CONSOLE,- ;Branch if not a console device
0224 843 UCB$W-TU58STS(R5),10$ ;
0228 844 CMPB G^EXE$GB_CPUTYPE,- ;Is this a 730 cpu?
022E 845 #PRS_SID_TYP730 ;
022F 846 BNEQ 10$ ;Branch if not
0231 847 DIVL2 #40,R0 ;Reduce wait time for 730 consoles
0234 848 10$: BBC #DD V_CONSOLE,- ;Branch if not console device
0236 849 UCB$W-TU58STS(R5),50$ ;
023A 850 MFPR #PRS_CSR,R1 ;Get CSR (console)
023D 851 20$: BITW #DD_RCSR_M_RDONE,R1 ;Test DONE bit
0242 852 BNEQ 30$ ;Branch if transfer done
0244 853 .BYTE 1[8] ;NOP's to slow loop to allow DMA I/O
024C 854 SOBGTR R0,10$ ;Branch if time not up
024F 855 MOVZWL #SS$_CTRLERR,R0 ;ERROR -- done bit never set
0254 856 BRB 35$ ;Read receiver buffer anyway
0256 857 30$: MOVZWL #SS$_NORMAL,R0 ;Set success status
0259 858 35$: BBC #DD V_CONSOLE,- ;Branch if not a console device
025B 859 UCB$W-TU58STS(R5),40$ ;
025F 860 MFPR #PRS_CSR,R1 ;Dump receiver buffer (console)
0262 861 RSB ;Return
0263 862 40$: MOVZWL DD_RBUF(R4),R1 ;Dump receiver buffer (unibus)
0267 863 RSB ;Return
0268 864 50$: MOVW DD_RCSR(R4),R1 ;Get receiver CSR (unibus)
026B 865 BRB 20$ ;Rejoin common code
```

50 00000000'GF 00004E20 8F C5 0216 841
OC 00CA C5 E1 0222 842
00000000'GF 91 0224 843
03 0228 844
03 022E 845
50 28 C6 022F 846
00 E1 0231 847
2E 00CA C5 0234 848
51 1C DB 0236 849
51 0080 8F B3 023A 850
12 12 023D 851
01'01'01'01'01'01'01'01' 0242 852
E5 50 F5 0244 853
50 0054 8F 3C 024C 854
03 11 024F 855
50 01 3C 0254 856
00 E1 0256 857
04 00CA C5 0259 858
51 1D DB 025B 859
05 025F 860
51 02 A4 3C 0262 861
05 0263 862
51 64 B0 0267 863
D0 11 0268 864
026B 865


```
0273 924 ;controller by two units at same time
0273 925
0273 926 DD_RESTARTIO: ;Restart the I/O operation after
0273 927 ;a powerfail recovery. We start
0273 928 ;here to avoid having to release
0273 929 ;and then request a new channel.
0273 930
0081 C5 90 0273 931 MOVB UCBSB_ERTMAX(R5),- ;Set error retry count
0080 C5 0277 932 UCBSB_ERTCNT(R5)
02 02 027A 933 BICW #UCBSB_DIAGBUF,- ;Clear diag. status bit
68 A5 027C 934 UCBSB_DEVSTS(R5)
07 E1 027E 935 BBC #IRPSV_DIAGBUF,- ;Branch if not diag. request
04 2A A3 0280 936 IRPSV_STS(R3),10$
02 AB 0283 937 BISW #UCBSB_DIAGBUF,- ;Set diag. status bit
68 A5 0285 938 UCBSB_DEVSTS(R5)
54 24 A5 D0 0287 939 10$: MOVL UCBSL_CRB(R5),R4 ;Get CRB address
0288 940 ASSUME IDBSL_CSR EQ 0 ;The following assumes this
54 2C B4 D0 0288 941 MOVL @CRBSL_INTD+VECSL_IDB(R4),R4 ;Get CSR address
028F 942
028F 943
028F 944 Buffer up the command packet.
52 00E2 C5 9E 028F 945 MOVAB UCBSK_DD_CPADDR(R5),R2 ;Get buffer address
82 0A02 8F B0 0294 946 MOVW #CMD_PKT_HDR,(R2)+ ;Set packet flag byte and byte count
062C 30 0299 947 BSBW SET_FUNCTION ;Determine device function
82 50 90 029C 948 MOVB R0,(R2)+ ;Put opcode into buffer
82 51 90 029F 949 MOVB R1,(R2)+ ;Put opcode modifier into buffer
02A2 950
02A2 951
02A2 952
02A2 953
02A2 954
50 54 A5 3C 02A2 955 MOVZWL UCBSW_UNIT(R5),R0 ;Get device unit #
02 00CA C5 E1 02A6 956 BBC #DD_V_CONSOLE,- ;Branch if not a console device
02 50 97 02AC 957 UCBSW_TU58STS(R5),20$
82 50 90 02AE 958 DECB R0 ;Decrement device unit
50 90 02AE 959 20$: MOVB R0,(R2)+ ;Put unit number into command packet
03 00CA C5 E1 02B3 960 CLRL R0 ;Assume not using MSRP
50 08 90 02B5 961 BBC #DD_V_USEMRSP,- ;Branch if not using MRSP
82 50 90 02B9 962 UCBSW_TU58STS(R5),30$
82 82 B4 02BF 963 MOVB #MRSP_M_SWITCH,R0 ;Set switch to use MRSP
62 7E A5 B0 02C1 964 30$: MOVB R0,(R2)+ ;Set command switch
00C0 C5 82 B0 02C5 965 CLRW (R2)+ ;Set sequence # (unused)
02CA 966 MOVW UCBSW_BCNT(R5),(R2) ;Put byte count into buffer
02CA 967 MOVW (R2)+,UCBSW_BCR(R5) ;Save # bytes to transfer
02CA 968
02CA 969
02CA 970
02CA 971
02CA 972
02CA 973
02CA 974
02CA 975
00BC C5 D0 02CA 975 MOVL IRPSL_MEDIA(R3),- ;Copy media address to UCB
00BC C5 DE 02CD 976 UCBSL_MEDIA(R5)
53 50 83 9A 02D0 977 MOVAL UCBSL_MEDIA(R5),R3 ;Get address of media address
51 83 9A 02D5 978 MOVZBL (R3)+,R0 ;Get SECTOR
7E 83 3C 02DB 979 MOVZBL (R3)+,R1 ;Get TRACK
02DB 980 MOVZWL (R3)+,-(SP) ;Get CYLINDER
```

For console TU58s, the physical device unit number is one less than the unit number stored in the UCB. This is a necessary to be compatible with existing software.

Convert the physical media address in IRPSL_MEDIA to an LBN. This is necessary because the TU58 controller expects an LBN, not a physical media address. The LBN is given by the formula:

$$\text{LBN} = (\text{CYLINDER} * (\text{TRACKS} / \text{CYLINDER}) + \text{TRACK}) * (\text{SECTORS} / \text{TRACK}) + \text{SECTOR}$$

```
53 45 A5 9A 02DE 981      MOVZBL UCB$B_TRACKS(R5),R3      ;Get TRACKS/CYLINDER
53 53 8E C4 02E2 982      MULL2 (SP)+,R3      ;R3 = C*(T/C)
51 53 C0 02E5 983      ADDL2 R3,R1      ;R1 = C*(T/C)+T
53 44 A5 9A 02E8 984      MOVZBL UCB$B_SECTORS(R5),R3      ;Get SECTORS/TRACK
51 53 C4 02EC 985      MULL2 R3,R1      ;R1 = (C*(T/C)+T)*(S/T)
82 50 51 A1 02EF 986      ADDW3 R1,R0,(R2)+      ;Put LBN into command packet buffer
      02F3 987      ;
      02F3 988      ; Compute the checksum for the command packet, and then
      02F3 989      ; insert it at the end of the packet.
      02F3 990      ;
51 00E2 C5 9E 02F3 991      MOVAB UCB$K_DD_CPADDR(R5),R1      ;Get command packet address
52 0C 3C 02F8 992      MOVZWL #<DD_CP_LEN - DD_CHKSM_LEN>,R2      ;Get command packet length
      05AA 30 02FB 993      BSBW CHECKSUM      ;Compute the checksum
00EE C5 50 B0 02FE 994      MOVW R0,UCB$W_DD_CPCKSM(R5)      ;Insert the checksum into packet
      0303 995      ;
      0303 996      ; DD_TRYAGN:
      0303 997      ;
      0303 998      ; Clear the End Packet buffer
      0303 999      ;
      30 BB 0303 1000      PUSHR #^M<R4,R5>      ;Save R4 and R5
      00 2C 0305 1001      MOVCS #0,-      ;Source length
00000000'EF 0307 1002      0,-      ;Source address
      00 030C 1003      #0,-      ;Fill character
      0E 030D 1004      #DD_EP_LEN,-      ;Destination length
      00F0 C5 030E 1005      UCB$K_DD_EPADDR(R5)      ;Destination address
      30 BA 0311 1006      POPR #^M<R4,R5>      ;Restore R4 and R5
      0313 1007      ;
      0313 1008      ; In case the I/O request has been restarted, some of the
      0313 1009      ; fields in the UCB must be reset to their initial values.
      0313 1010      ;
53 58 A5 D0 0313 1011      MOVL UCB$L_IRP(R5),R3      ;Get IRP address
      2C A3 7D 0317 1012      MOVQ IRP$L_SVAPTE(R3),-      ;Restore UCB$L_SVAPTE,
      78 A5 031A 1013      UCB$L_SVAPTE(R5)      ;UCB$W_BCNT and UCB$W_BOFF
      7E A5 B0 031C 1014      MOVW UCB$W_BCNT(R5),-      ;Restore UCB$W_BCR
00C0 C5 031F 1015      UCB$W_BCR(R5)      ;
      02 A8 0322 1016      BISW #DD_M_PASS1,-      ;Reset bit in TU58STS
00CA C5 0324 1017      UCB$W_TU58STS(R5)      ;
      0327 1018      ;
      0327 1019      ; Send the command packet to the device.
      0327 1020      ;
      00E2 C5 9E 0327 1021      MOVAB UCB$K_DD_CPADDR(R5),-      ;Get command packet address
00D4 C5 032B 1022      UCB$K_DD_MSGPKT(R5)      ;
      0E B0 032E 1023      MOVW #DD_CP_LEN,-      ;Get command packet length.
00D8 C5 0330 1024      UCB$W_DD_MSGLEN(R5)      ;
      0333 1025      SEND_PACKET      ;Send the command packet
      0341 1026      ;
      0341 1027      ; Drop thru to GET_RESPONSE
      0341 1028      ;
```

```
0341 1030 :  
0341 1031 : This sequence of code is executed after each successful  
0341 1032 : transmission/reception of a message packet. GET_RESPONSE  
0341 1033 : merely gets the next byte sent from the device, and uses  
0341 1034 : that byte to decide what to do next.  
0341 1035 :  
0341 1036 GET_RESPONSE: ;Get the TU58's response  
0341 1037 GET_BYTE ;Get a byte  
51 0091 C5 90 0358 1038 MOVB UCBSB_SPR(R5),R1 ;Move to R1 for convenience  
51 01 91 0360 1039 CMPB #DD_FLAG_DATA,R1 ;Data flag?  
51 18 13 0363 1040 BEQL READ_DATA ;Branch if data flag  
51 10 91 0365 1041 CMPB #DD_FLAG_CONT,R1 ;Continue flag?  
51 0D 13 0368 1042 BEQL 10$ ;Branch if continue flag  
51 02 91 036A 1043 CMPB #DD_FLAG_CNTL,R1 ;Control flag?  
50 0054 8F 3C 036D 1044 BEQL 20$ ;If control flag then branch  
01ED 31 0374 1046 BRW CONT_ERROR ;Assume controller error  
00C0 31 0377 1047 10$: BRW WRITE_DATA ;Controller protocol error  
0143 31 037A 1048 20$: BRW END_PACKET ;Write to the device  
;Get the end packet
```

```
037D 1050 :  
037D 1051 : The following code sequence services READ requests by  
037D 1052 : transferring a data packet from the device to the user's buffer.  
037D 1053 :  
037D 1054 READ_DATA: ;Service READ request  
00D0 D5 51 90 037D 1055 MOVB R1,@UCBSL_DD_DPTR(R5) ;Buffer data flag  
50 01 9A 0382 1056 GET_BYTE ;Get the packet byte count  
0091 C5 90 039C 1057 MOVZBL #DD DPBCNT,R0 ;Put offset in R0  
00D0 D540 039F 1058 MOVB UCBSB_SPR(R5),- ;Buffer the byte count  
03A3 1059 @UCBSL_DD_DPTR(R5)[R0] ;  
03A7 1060 :  
03A7 1061 : Before getting the data from the device, ensure the data packet  
03A7 1062 : byte count is correct. Failure to do so can cause the driver to  
03A7 1063 : overwrite nonpaged pool should the byte count be incorrect. Note  
03A7 1064 : that if the number of bytes remaining to be transferred is greater  
03A7 1065 : than 128 (decimal), then the packet byte count must be 128. If the  
03A7 1066 : number of bytes remaining to be transferred is less than or equal to  
03A7 1067 : 128, then the packet byte count must equal that number.  
52 0091 C5 9A 03A7 1068 MOVZBL UCBSB_SPR(R5),R2 ;Get the PBC  
51 0080 8F 3C 03AC 1070 MOVZWL #128,R1 ;Set up R1 for the comparisons  
51 00C0 C5 B1 03B1 1071 CMPW UCBSW_BCR(R5),R1 ;Is the BCR less than 128?  
51 00C0 C5 1E 03B6 1072 BGEQU 100$ ;Branch if not  
51 51 52 D1 03B8 1073 MOVZWL UCBSW_BCR(R5),R1 ;Get the BCR  
63 12 03BD 1074 100$: CMPL R2,R1 ;Is the PBR what it ought to be?  
03C0 1075 BNEQ 69$ ;Branch if not (error)  
03C2 1076 :  
03C2 1077 : Get the rest of the data packet, including the checksum.  
03C2 1078 :  
00D4 C5 00D0 D540 50 96 03C2 1079 INCB R0 ;Set offset to point to next byte  
9E 03C4 1080 MOVAB @UCBSL_DD_DPTR(R5)[R0],- ;Get pointer into packet buffer  
50 0091 C5 9B 03CC 1081 UCBSL_DD_MSGPKT(R5) ;  
00D8 C5 50 02 A1 03CC 1082 MOVZBL UCBSB_SPR(R5),R0 ;Get packet byte count  
03D1 1083 ADDW3 #DD CRKSM_LEN,R0 ;Allow room for the packet checksum  
03D7 1084 UCBSW_DD_MSGLEN(R5) ;  
03D7 1085 GET_PACKET ;Get the data packet  
03E5 1086 :  
03E5 1087 : Now transfer the data in the data packet buffer to  
03E5 1088 : the users buffer, and then await the TU58's next byte.  
03E5 1089 : On return from MOVTOUSER, R1 points to the end of the packet buffer.  
03E5 1090 :  
51 50 02 9A 03E5 1091 MOVZBL #DD DATA,R0 ;Put offset into R0  
52 00D0 D540 9E 03E8 1092 MOVAB @UCBSL_DD_DPTR(R5)[R0],R1 ;Get address of data  
52 0091 C5 9A 03EE 1093 MOVZBL UCBSB_SPR(R5),R2 ;Get # of data bytes  
03F3 1094 MOVTOUSER ;Move data  
0411 1095 :  
0411 1096 : Calculate the packet checksum and compare it with the checksum  
0411 1097 : received from the device. If no match then the data was garbled  
0411 1098 : during transmission and the I/O operation must be retried.  
0411 1099 : On return from CHECKSUM, R1 points to the packet buffer checksum.  
0411 1100 :  
51 50 51 D0 0411 1101 MOVL R1,R0 ;Save pointer into buffer  
51 00D0 C5 D0 0414 1102 MOVL UCBSL_DD_DPTR(R5),R1 ;Get buffer address  
52 50 51 C3 0419 1103 SUBL3 R1,R0,R2 ;Calculate the buffer length  
0488 30 041D 1104 BSBW CHECKSUM ;Calculate the checksum  
61 50 B1 0420 1105 CMPW R0,(R1) ;Compare checksums  
08 13 0423 1106 BFQL 10$ ;Branch if no errors
```

DDDRIVER
V04-000

- TU58 DC100 TAPE CARTRIDGE DRIVER N 2
STARTIO ROUTINE

16-SEP-1984 00:19:23 VAX/VMS Macro V04-00
5-SEP-1984 00:12:11 [DRIVER.SRC]DDDRIVER.MAR;1

Page 26
(1)

DC
VC

50	01F4 8F	B0	0425	1107	69\$:	MOVW	#SS\$ PARITY,R0	;Put error code in R0
	0137	31	042A	1108		BRW	CONT_ERROR	;Attempt to retry operation
			042D	1109	:			
			042D	1110	:			
			042D	1111	:			
			042D	1112	10\$:			
50	0091 C5	9B	042D	1112		MOVZBW	UCB\$B SPR(R5),R0	;Get data packet byte count
00C0 C5	50	A2	0432	1113		SUBW	R0,UCB\$W BCR(R5)	;Update byte transfer count
	FF07	31	0437	1114		BRW	GET_RESPONSE	;Await next byte from device

```
043A 1116 :  
043A 1117 : The following code services a WRITE request by transferring data  
043A 1118 : from the user's buffer to the TUSB. The transfer is made by  
043A 1119 : sending data packets of <= 128 bytes. When sending data we do  
043A 1120 : not have to worry about data over-run.  
043A 1121 :  
043A 1122 WRITE_DATA: ;Send data to the device  
00D0 01 90 043A 1123 MOV B #DD_FLAG_DATA,- ;Buffer data flag  
043C 1124 @UCBSL_DD_DPTR(R5) ;  
043F 1125 :  
043F 1126 : Calculate the packet byte count.  
043F 1127 :  
00C0 C5 B1 043F 1128 CMPW UCBSW_BCR(R5),- ;Can we send a full packet?  
0080 8F 07 1A 0443 1129 #DD_MAX_PKT_BCNT ;  
51 00C0 C5 9B 0446 1130 BGTRU 10$- ;Branch if yes  
04 11 0448 1131 MOVZBW UCBSW_BCR(R5),R1 ;Set byte count <= 128  
51 80 8F 9B 044D 1132 BRB 20$ ;Rejoin common code  
00C D540 51 9A 044F 1133 10$: MOVZBW #DD_MAX_PKT_BCNT,R1 ;Set byte count = 128  
00C0 C5 51 9A 0453 1134 20$: MOVZBL #DD_DPBCNT,R0 ;Put offset into R0  
0456 1135 MOV B R1,@UCBSL_DD_DPTR(R5)[R0] ;Put byte count into data packet  
045C 1136 SUBW R1,UCBSW_BCR(R5) ;Calc new UCBSW_BCR  
0461 1137 :  
0461 1138 : Transfer the data from the user's buffer to the packet buffer.  
0461 1139 : On return from IOC$MOVFRUSER, R1 = pointer into packet buffer.  
0461 1140 :  
52 51 9A 0461 1141 MOVZBL R1,R2 ;Get byte count  
50 02 9A 0464 1142 MOVZBL #DD_DATA,R0 ;Put offset into R0  
51 00D0 D540 9E 0467 1143 MOVAB @UCBSL_DD_DPTR(R5)[R0],R1 ;Get address of data w/i data packet  
046D 1144 MOVFROMUSER ;Move data  
048B 1145 :  
048B 1146 : Create the data packet checksum. On return from CHECKSUM,  
048B 1147 : R1 points to the end of the data buffer.  
048B 1148 :  
51 50 51 D0 048B 1149 MOVL R1,R0 ;Save pointer into buffer  
51 00D0 C5 D0 048E 1150 MOVL UCBSL_DD_DPTR(R5),R1 ;Get buffer address  
52 50 51 C3 0493 1151 SUBL3 R1,R0,R2 ;Calculate buffer length  
040E 30 0497 1152 BSBW CHECKSUM ;Calculate checksum  
81 50 B0 049A 1153 MOVW R0,(R1)+ ;Put checksum into buffer  
049D 1154 :  
049D 1155 : Send the data packet to the device.  
049D 1156 :  
00D0 C5 D0 049D 1157 MOVL UCBSL_DD_DPTR(R5),- ;Get buffer address  
00D4 C5 04A1 1158 UCBSL_DD_MSGPKT(R5) ;  
50 51 00D4 C5 C3 04A4 1159 SUBL3 UCBSL_DD_MSGPKT(R5),R1,R0 ;Calculate buffer length  
00D8 C5 50 B0 04AA 1160 MOVW R0,UCBSW_DD_MSGLEN(R5) ;Move to input cell  
04AF 1161 SEND_PACKET ;Send data packet  
FE81 31 04BD 1162 BRW GET_RESPONSE ;Await next byte from device
```

```
04C0 1164 :
04C0 1165 : This code will get the end packet and interpret the device
04C0 1166 : status code.
04C0 1167 :
04C0 1168 END_PACKET: ;Intrepret the end packet
00F0 C5 51 90 04C0 1169 MOVAB R1,UCBSB_DD_EPFLAG(R5) ;Buffer flag byte
04C5 1170 :
04C5 1171 : Read in the rest of the end packet, including the checksum.
04C5 1172 :
00F1 C5 9E 04C5 1173 MOVAB UCBSB_DD_EPBCNT(R5),- ;Get buffer address
00D4 C5 04C9 1174 UCBSL_DD_MSGPKT(R5) ;
00D8 C5 0D 80 04CC 1175 MOVW #<DD_EP[EN-1],- ;Get buffer length
04CE 1176 UCBSB_DD_MSGLEN(R5) ;
04D1 1177 GET_PACKET ;Get end packet
04DF 1178 :
04DF 1179 : Calculate the packet checksum and compare it to the checksum sent
04DF 1180 : by the device. If no match, then the data was garbled during
04DF 1181 : transmission, and the I/O request must be retried.
04DF 1182 :
51 00F0 C5 9E 04DF 1183 MOVAB UCBSB_DD_EPADDR(R5),R1 ;Get Command packet buffer address
52 0C 3C 04E4 1184 MOVZWL #<DD_CP[EN-DD_CHKSM_LEN],R2 ;Get buffer length
03BE 30 04E7 1185 BSBW CHECKSUM ;Calculate checksum
00FC C5 50 81 04EA 1186 CMPW R0,UCBSB_DD_EPCKSM(R5) ;Compare checksums
07 13 04EF 1187 BEQL 10$ ;Branch if match
50 01F4 8F 80 04F1 1188 MOVW #SS$_PARITY,R0 ;Put error code in R0
6C 11 04F6 1189 BRB CONT_ERROR ;Attempt to retry request
04F8 1190 :
04F8 1191 : Get the device status and see how things went.
04F8 1192 :
51 00F3 C5 9A 04F8 1193 10$: MOVZBL UCBSB_DD_EPSTS(R5),R1 ;Get device status code
50 01 80 04FD 1194 MOVW #SS$_NORMAL,R0 ;Assume success
00 51 91 0500 1195 CMPB R1,#DD_STS_NORMAL ;Test status
37 18 0503 1196 BGEQ DD_EXIT ;Branch if success or success w/ retries
0505 1197 : ;- assumes value of 0 and 1 respectively
0505 1198 :
0505 1199 : If we get this far, something went wrong.
0505 1200 : Log a device error, and see if the device-specific
0505 1201 : error code can be mapped directly to a VMS error code.
0505 1202 : If not, then map the error into SS$_CTRLERR. Note that
0505 1203 : the operation will not be retried for this type of error.
0505 1204 :
00000000'GF 16 0505 1205 JSB G^ERL$DEVICERR ;Log the error
50 01C4 8F 80 0508 1206 MOVW #SS$_NONEXDRV,R0 ;Assume bad unit #
51 F8 8F 91 0510 1207 CMPB #DD_STS_BADUNIT,R1 ;
26 13 0514 1208 BEQL DD_EXIT ;
50 01A4 8F 80 0516 1209 MOVW #SS$_MEDOFL,R0 ;Assume no cartridge
51 F7 8F 91 0518 1210 CMPB #DD_STS_NOCART,R1 ;
18 13 051F 1211 BEQL DD_EXIT ;
50 025C 8F 80 0521 1212 MOVW #SS$_WRTLCK,R0 ;Assume writelock error
51 F5 8F 91 0526 1213 CMPB #DD_STS_WRTLCK,R1 ;
10 13 052A 1214 BEQL DD_EXIT ;
50 005C 8F 80 052C 1215 MOVW #SS$_DATACHECK,R0 ;Assume datacheck error
51 EF 8F 91 0531 1216 CMPB #DD_STS_DATACHK,R1 ;
05 13 0535 1217 BEQL DD_EXIT ;
0537 1218 :
0537 1219 : Map all other errors into CONTROLLER ERRORS, but
0537 1220 : return device status code in device dependent
```

DDDRIVER
V04-000

- TUSB DC100 TAPE CARTRIDGE DRIVER^{D 3}
STARTIO ROUTINE

16-SEP-1984 00:19:23 VAX/VMS Macro V04-00
5-SEP-1984 00:12:11 [DRIVER.SRC]DDDRIVER.MAR;1

Page 29
(1)

DDD
V04

```

      0537 1221 :      field of the IOSB.
      0537 1222 :
50 0054 8F B0 0537 1223 :      MOVW    #SSS_CTRLERR,R0      ;Assume controller error
      053C 1224 :
      053C 1225 :      Fall through to DD_EXIT
      053C 1226 :
```

```
053C 1228 .SBTTL COMMON EXIT ROUTINE
053C 1229 :
053C 1230 : Common exit routine. Exit status is in the low word of R0.
053C 1231 :
053C 1232 DD_EXIT: ;Common exit routine
053C 1233 MOVZWL R0,-(SP) ;Save I/O status
053F 1234 JSB G^I0C$DIAGBUFILL ;Fill diagnostic buffer if present.
0545 1235 RELCHAN ;Release channel
054B 1236 :
054B 1237 : Put the IOSB info into R0 and R1 and exit the driver.
054B 1238 :
054B 1239 :
054E 1240 POPL R0 ;Restore I/O status
0552 1241 SUBW3 UCBSW-BCR(R5),- ;Calc bytes transferred
0555 1242 UCBSW-BCNT(R5),R2 ;
0559 1243 ASHL #16,R2,R2 ;Shift count to high word
055C 1244 BISL R2,R0 ;Merge count into status longword
055E 1245 CLRL R1 ;Clear second status longword
REQCOM ;That's all folks!
```

```
0564 1247 .SBTTL Controller error handler
0564 1248 :
0564 1249 : This code attempts to recover from errors encountered during
0564 1250 : a data transfer. Control is transferred to DD_RETRY only on
0564 1251 : device timeout recovery. All other errors trap to CONT_ERROR.
0564 1252 :
0564 1253 : The only way to recover from an error is to set the controller to
0564 1254 : a known state, via the TUS8 INIT sequence, and retry the entire I/O
0564 1255 : operation. If the INIT sequence fails, then exit with a controller
0564 1256 : error.
0564 1257 :
0564 1258 CONT_ERROR:
0564 1259     MOVZWL R0,UCBSL_DD_BUFWIN(R5) ;Recover from controller error
0569 1260     BSBW DD_SAVEREG ;Save the error status code
056C 1261     JSB G^ERL$DEVICERR ;Save device registers
0572 1262     ;Log the error
0572 1263 :
0572 1264 : This entry point is used by the timeout routine. It is
0572 1265 : necessary to enter here to avoid overwriting the register
0572 1266 : save area in the UCB that was written by the timeout routine.
0572 1267 :
0572 1267 DD_RETRY:
0572 1268     BSBB RESET_CONTROLLER ;Reset the device controller
0574 1269     BLBC R0,10$ ;Branch if controller init failure
0577 1270     DECB UCBSB_ERTCNT(R5) ;Decrement error retry count
057B 1271     BLEQ 10$ ;Branch if no retries left
057D 1272     BBS #10$V_INHRETRY,- ;Branch if no retry requested
057F 1273     UCBSW_FUNC(R5),10$ ;
0583 1274     BRW DD_TRYAGN ;Retry I/O function
0586 1275 10$: MOVW UCBSL_DD_BUFWIN(R5),R0 ;Restore the error status code
058B 1276     BRB DD_EXIT ;Exit the driver
058D 1277
```

00CC C5 50 3C 0564 1259
00F4 30 0569 1260
00000000'GF 16 056C 1261

44 10 0572 1268
OF 50 E9 0574 1269
0080 C5 97 0577 1270
09 15 057B 1271
OF E0 057D 1272
03 009A C5 057F 1273
FD7D 31 0583 1274
50 00CC C5 80 0586 1275
AF 11 058B 1276
058D 1277

```
0580 1279 .SBTTL TIMEOUT and POWERFAIL recovery
0580 1280 :++
0580 1281 : This routine is called in the event of a device timeout.
0580 1282 : The timeout could be caused by a failure of the TU58 hardware
0580 1283 : or the hardware connecting the TU58 to the host machine, or
0580 1284 : the host machine could have undergone powerfail recovery.
0580 1285 :
0580 1286 : Input:
0580 1287 :
0580 1288 :     IPL      = Device IPL
0580 1289 :     (SP)     = Return address
0580 1290 :     R0-R3    = Scratch
0580 1291 :     R4       = CSR address
0580 1292 :     R5       = UCB address
0580 1293 :--
0580 1294
00D0 30 0580 1295 DD_TIME_OUT:
51 D4 0580 1296 BSBW DD_SAVEREG ;Move registers into UCB
0305 30 0590 1297 CLRL R1 ;Prepare to disable interrupts
02F3 30 0592 1298 BSBW RCSR ;Disable receive interrupts
05 0595 1299 BSBW SCSR ;Disable transmit interrupts
14 64 A5 E4 0598 1300 SETIPL UCBSB FIPL(R5) ;Lower IPL to FIPL
00000000 GF 16 059C 1301 BBSC #UCBSV POWER,- ;Power failure?
06 E5 059E 1302 UCBSW STS(R5),DD_PWF ;Branch if yes
00 64 A5 05A1 1303 JSB G^ERL$DEVICTMO ;Log timeout error
022C 8F 3C 05A7 1304 BBCC #UCBSV TIMEOUT,- ;Reset status
00CC C5 05A9 1305 UCBSW STS(R5),10$ ;
BD 11 05AC 1306 10$: MOVZWL #SS$ TIMEOUT,- ;Save the timeout status
0580 1307 UCBSW DD_BUFWIN(R5) ;
0585 1308 BRB DD_RETRY ;Init the controller and retry the I/O
0585 1309
0585 1310
0585 1311
0585 1312 :
0585 1313 : DD_PWF
0585 1314 :
0585 1315 : This routine is branched after the device timeout caused by
0585 1316 : a powerfail. The I/O operation is retried. Note that the
0585 1317 : controller has already been reset by the unit initialization
0585 1318 : routines, which are called by the operating system as part
0585 1319 : of its normal powerfail recovery.
0585 1320 :
0585 1321 DD_PWF:
FCBB 31 0585 1322 BRW DD_RESTARTIO ;Start function over again
```

```

0588 1324 .SBTTL RESET_CONTROLLER
0588 1325 :++
0588 1326 : RESET_CONTROLLER
0588 1327 :
0588 1328 : This routine will set the device controller to a known state.
0588 1329 : To initialize the TUSB controller, it is necessary to perform
0588 1330 : the following steps:
0588 1331 :
0588 1332 : - Set the BREAK bit in the transmitter CSR and hold
0588 1333 : it for at least two character times.
0588 1334 : - Clear the Break bit.
0588 1335 : - Dump the receiver buffer. The contents are unimportant.
0588 1336 : - Send two INIT characters.
0588 1337 : - Dump the receiver buffer. The response must be equal to
0588 1338 : DD_FLAG_CONT. If not, the initialization sequence failed.
0588 1339 :
0588 1340 : The initialization sequence must be done with IPL equal to IPL_POWER
0588 1341 : to lock out all interrupts.
0588 1342 :
0588 1343 : Input:
0588 1344 :
0588 1345 : R0-R3 = Scratch
0588 1346 : R4 = CSR address
0588 1347 : R5 = UCB address
0588 1348 :
0588 1349 : Output:
0588 1350 :
0588 1351 : R0 = $$$_NORMAL if the reset worked, $$$_CTRLERR if not.
0588 1352 :--
0588 1353 :
0588 1354 RESET_CONTROLLER:
0588 1355 :
0588 1356 : Set the BREAK condition. Clear it after a short wait.
0588 1357 :
51 01 3C 0588 1358 MOVZWL #DD_XCSR_M_BREAK,R1 ;Put BREAK into R1
0588 1359 DSBINT ;Disable interrupts
02C7 30 05C1 1360 BSBW SCSR ;Set BREAK condition
05C4 1361 TIMEWAIT #<2*MAXCHRTIM>,#1,#0,W ;Loop for 2 character times
51 04 05EB 1362 CLRL R1 ;Clear R1
029B 30 05ED 1363 BSBW SCSR ;Clear break condition
05F0 1364 :
05F0 1365 : Dump the receiver buffer.
05F0 1366 :
FC23 30 05F0 1367 BSBW DUMP_RECVR_BUF ;Dump buffer and discard contents
05F3 1368 :
05F3 1369 : Send two INIT characters.
05F3 1370 :
50 00D4 C5 DE 05F3 1371 MOVAL UCBSL_DD_MSGPKT(R5),R0 ;Get address of buffer pointer
60 00CE C5 3E 05F8 1372 MOVAW 2+UCBSL_DD_BUFWIN(R5),(R0);Get address of message buffer
00 B0 0404 8F B0 05FD 1373 MOVW #TWO_INITS,a(R0) ;Put INIT characters into buffer
04 A0 02 B0 0603 1374 MOVW #2,4(R0) ;Save # of bytes to send
FBA8 30 0607 1375 BSBW SND_PKT_NOINT ;Send the packet
10 50 E9 060A 1376 BLBC R0,20$ ;Branch if error
060D 1377 :
060D 1378 : The controller should respond with a DD_FLAG_CONT.
060D 1379 : If it does not, then exit with a controller error.
060D 1380 : R0 will contain a meaningful status code on return

```

			060D	1381		; from dump_recvr_buf.	
			060D	1382		.	
	FC06	30	060D	1383	BSBW	DUMP_RECVR_BUF	;Get controller response
50	01	3C	0610	1384	MOVZWL	#SSS-NORMAL,R0	;Assume success status
51	10	91	0613	1385	CMPB	#DD_FLAG_CONT,R1	;Is it the correct response?
	05	13	0616	1386	BEQL	20\$	;Branch if true
50	0054	BF	3C	0618	MOVZWL	#SSS_CTRLERR,R0	;Set error status
		05	061D	1388	ENBINT		;Enable interrupts
			0620	1389	RSB		;Return

20\$:

```
0621 1391 .SBTTL REGISTER DUMP ROUTINE
0621 1392 :++
0621 1393 : DD_REGDUMP - REGISTER DUMP ROUTINE
0621 1394 :
0621 1395 : FUNCTIONAL DESCRIPTION:
0621 1396 :
0621 1397 : This routine is called to save the device registers in a specified
0621 1398 : buffer. It is called from the device error logging routine and from
0621 1399 : the diagnostic buffer fill routine.
0621 1400 :
0621 1401 : INPUTS:
0621 1402 : R0 = ADDRESS OF REGISTER SAVE BUFFER
0621 1403 : R4 = ADDRESS OF DEVICE CONTROL STATUS REGISTER
0621 1404 : R5 = ADDRESS OF UNIT CONTROL BLOCK
0621 1405 : OUTPUTS:
0621 1406 : DEVICE REGISTERS ARE MOVED INTO THE SPECIFIED BUFFER.
0621 1407 : R0 CONTAINS THE ADDRESS OF THE NEXT EMPTY LONGWORD IN THE BUFFER.
0621 1408 : ALL REGISTERS EXCEPT R1 AND R2 ARE PRESERVED.
0621 1409 :
0621 1410 :--
0621 1411 DD_REGDUMP:
51 80 08 D0 0621 1412 MOVL #DD_ERRBUF_LEN_L,(R0)+ ;Insert # of longwords dumped
52 52 04 D0 0624 1413 MOVL #DD_NUM_REGS,R2 ;Store number of registers
00DA C5 3E 0627 1414 MOVAW UCB$W_DD_XCSR(R5),R1 ;Get address of first reg.
80 80 81 3C 062C 1415 10$: MOVZWL (R1)+,(R0)+ ;Dump registers into buffer
FA 52 F5 062F 1416 SOBGTR R2,10$ ;If GTR - more to go
0632 1417 :
0632 1418 : Now dump the Command and End packets to the error buffer.
0632 1419 :
52 52 07 D0 0632 1420 MOVL #7,R2 ;Get length of combined packets
80 80 81 D0 0635 1421 20$: MOVL (R1)+,(R0)+ ;Dump longword to buffer
FA 52 F5 0638 1422 SOBGTR R2,20$ ;If GTR - more to go
05 063B 1423 RSB ;Return
```

```
063C 1425 .SBTTL INTERRUPT SERVICE ROUTINE
063C 1426 :
063C 1427 :++
063C 1428 : DD$INT - TUSB INTERRUPT ROUTINE
063C 1429 :
063C 1430 : This routine is entered via a JSB instruction when an
063C 1431 : interrupt occurs. The state of the stack on entry is:
063C 1432 :
063C 1433 : 00(SP) = ADDRESS OF IDB ADDRESS.
063C 1434 : 04(SP) = SAVED R0.
063C 1435 : 08(SP) = SAVED R1.
063C 1436 : 12(SP) = SAVED R2.
063C 1437 : 16(SP) = SAVED R3.
063C 1438 : 20(SP) = SAVED R4.
063C 1439 : 24(SP) = SAVED R5.
063C 1440 : 28(SP) = SAVED INTERRUPT PC
063C 1441 : 32(SP) = INTERRUPT PSL.
063C 1442 :
063C 1443 : Interrupt dispatching occurs as follows:
063C 1444 :--
063C 1445 DD_INT::
063C 1446 MOVL @ (SP)+, R3 ;Get IDB address
063C 1447 MOVQ (R3), R4 ;Get CSR and UCB address
063C 1448 MOVQ UCB$L FR3(R5), R3 ;Restore R3 and R4
063C 1449 BBC #UCB$V INT, - ;If clr -interrupt not expected
063C 1450 UCB$W STS(R5), DD_UNSOINT
063C 1451 JMP @UCB$C_FPC(R5) ;Jump to interrupt ret. address
063C 1452 DD_UNSOINT:
063C 1453 :
063C 1454 : In order to dismiss the interrupt, the receiver buffer must be read.
063C 1455 :
063C 1456 BBC #DD V_CONSOLE, - ;Branch if not console device
063C 1457 UCB$W TU58STS(R5), 20$ ;
063C 1458 MFPR #PR$ CSR, R1 ;Read buffer for CONSOLE TU58
063C 1459 10$: POPR #^M<R0, R1, R2, R3, R4, R5> ;Restore R0-R5
063C 1460 REI ;Dismiss the interrupt
063C 1461 20$: MOVW DD_RBUF(R4), R1 ;Read buffer for UNIBUS TU58
063C 1462 BRB 10$ ;Dismiss the interrupt
063C 1463
```

53 9E D0
54 63 7D
53 10 A5 7D
03 64 A5 E1
0C B5 17

06 00CA 00 E1
51 1D C5 DB
3F BA
02 0659 1460
51 02 A4 B0
F7 11 065E 1462
0660 1463

```
0660 1465 .SBTTL LOCAL SUBROUTINES
0660 1466
0660 1467 :++
0660 1468
0660 1469 : DD_SAVEREG
0660 1470
0660 1471 : ABSTRACT: Store the device registers in the UCB, so they may
0660 1472 : later be passed to the error logger.
0660 1473
0660 1474 : INPUT: R4 = CSR Address
0660 1475 : R5 = UCB address
0660 1476
0660 1477 : OUTPUT: Registers saved in UCB.
0660 1478
0660 1479 : SIDE EFFECTS: R0,R2 are over-written.
0660 1480
0660 1481 : Note that for CONSOLE devices, the xmitter buffer is
0660 1482 : a write-only register. Code around this by saving the
0660 1483 : image of the buffer as it is loaded in the routine
0660 1484 : SEND_PACKET. Also note that the MFPR instruction has
0660 1485 : a longword context, so the CONSOLE devices registers
0660 1486 : must be saved carefully, so other locations in the UCB
0660 1487 : are not overwritten.
0660 1488
0660 1489 :--
0660 1490 DD_SAVEREG:
52 00DA C5 3E 0660 1491 MOVAW UCB$K_DD REGBUF(R5),R2 ;Save device registers.
12 00CA C5 E1 0665 1492 BBC #DD_V_CONSOLE,- ;Get address of buffer
50 1E DB 0667 1493 UCB$W_TUSBSTS(R5),10$ ;Branch if not console device
82 50 B0 066B 1494 MFPR #PR$_CSTS,R0 ;Get xmitter CSR
02 A2 1C DB 066E 1495 MOVW R0,(R2)+ ;Save xmitter CSR
50 1D DB 0671 1496 MFPR #PR$_CSRS,2(R2) ;Save receiver CSR
04 A2 50 B0 0675 1497 MFPR #PR$_CSRD,R0 ;Get receiver buffer
82 04 A4 B0 0678 1498 MOVW R0,4(R2) ;Save receiver buffer
82 06 A4 B0 067C 1499 RSB ;Return
82 82 64 B0 067D 1500 10$: MOVW DD_XCSR(R4),(R2)+ ;Save xmitter CSR
82 02 A4 B0 0681 1501 MOVW DD_XBUF(R4),(R2)+ ;Save xmitter buffer
82 02 A4 B0 0685 1502 MOVW DD_RCSR(R4),(R2)+ ;Save receiver CSR
05 0688 1503 MOVW DD_RBUF(R4),(R2)+ ;Save receiver buffer
05 068C 1504 RSB ;Return
```

```
068D 1506 .SBTTL GET_PACKET_C
068D 1507 :++
068D 1508 :
068D 1509 GET_PACKET_C
068D 1510 :
068D 1511 ABSTRACT: Get a message packet from a console TU58. Because of
068D 1512 : the unique nature of the TU58, this routine is optimized
068D 1513 : for speed. The TU58 generates an inordinate number of
068D 1514 : interrupts, and can use a large fraction of the processor
068D 1515 : during normal operation. In order to reduce overhead, some
068D 1516 : extreme measures have been taken in the coding of this routine.
068D 1517 :
068D 1518 INPUT: R4 = CSR address
068D 1519 : R5 = UCB address
068D 1520 : UCBSL_DD_MSGPKT(R5) = Message packet buffer address
068D 1521 : UCBSW_DD_MSGLEN(R5) = Message packet buffer length
068D 1522 :
068D 1523 OUTPUT: None.
068D 1524 :
068D 1525 :
068D 1526 NOTES: 1) This routine enables the device interrupts at the
068D 1527 : beginning of the message packet and does not
068D 1528 : disable them until the entire message packet has
068D 1529 : been transferred.
068D 1530 :
068D 1531 : 2) The WFIKPC macro is not used. Instead, the code
068D 1532 : is placed inline to avoid the cost in time inherent
068D 1533 : in the macro.
068D 1534 :
068D 1535 : 3) To save the overhead of IOFORKing after each byte
068D 1536 : transferred, the routine will not IOFORK until
068D 1537 : the entire message packet has been transferred.
068D 1538 :
068D 1539 : 4) The large time (40 seconds) spent waiting for a device timeout
068D 1540 : is necessary because of the slowness of the TU58. It takes on
068D 1541 : the order of 30 - 40 seconds for the device to position the
068D 1542 : tape from one end of the cartridge to another.
068D 1543 :
068D 1544 :--
068D 1545 :
068D 1546 GET_PACKET_C: ;Get a message packet
068D 1547 :
068D 1548 : The following code is done only once, to set up
068D 1549 : for the optimized interrupt service loop.
068D 1550 :
068D 1551 MOVL (SP)+,UCBSL_DPC(R5) ;Store return address
068D 1552 BICW #UCBSM_TIMEOUT,- ;Clear timeout occurred bit
068D 1553 UCBSW_STS(R5) ;
068D 1554 :
068D 1555 : If this is an MRSP TU58 then set the interrupt dispatch address to
068D 1556 : point to the code that will handle the MRSP protocol. Otherwise,
068D 1557 : set the dipatch address to a routine to handle the normal RSP TU58.
068D 1558 :
068D 1559 MOVAL L^300$,UCBSL_FPC(R5) ;Assume this is an MRSP TU58.
068D 1560 BBS #DD_V_USEMRSP,- ;Branch if we are to use MRSP
068D 1561 UCBSW_TU58STS(R5),10$ ;
068D 1562 MOVAL L^600$,UCBSL_FPC(R5) ;Set address for RSP TU58
```

009C C5 8E DO 068D 1551
0040 8F AA 0692 1552
64 A5 0696 1553
0698 1554
0698 1555
0698 1556
0698 1557
0698 1558
OC A5 000006E4'EF DE 0698 1559
03 EO 06A0 1560
0B 00CA C5 06A2 1561
OC A5 0000070E'EF DE 06A6 1562

```
00D4 C5 D0 C0AE 1563 10$: MOVL UCB$LD_DDMSGPKT(R5),- ;Get address of message packet
      10 A5 06B2 1564 UCB$LD_FR3(R5)
00D8 C5 3C 06B4 1565 MOVZWL UCB$W_DDMSGLEN(R5),- ;Get length of message
      14 A5 06B8 1566 UCB$LD_FR4(R5)
      06BA 1567 DSBINT UCB$B_DIPL(R5) ;Lock out device interrupts
1C 00000040 8F DA 06C1 1568 MTPR #DD_RCSR_M_RIE,#PRS_CSRS;Enable interrupts
      03 AB 06C8 1569 BISW #UCB$M_TIM:UCB$M_INT,- ;Set INTERRUPT and TIMEOUT enabled
      64 A5 06CA 1570 UCB$W_STS(R5)
      34 C1 06CC 1571 ADDL3 #LONG_WAIT,- ;Compute timeout time for entire transfer.
00000000 GF 06CE 1572 G*EXE$GL_ABSTIM,- ;This will save recomputing it for each
      6C A5 06D3 1573 UCB$LD_DUETIM(R5) ;byte transferred.
      06D5 1574 :
      06D5 1575 :
      06D5 1576 :
      06D5 1577 :
      06D5 1578 :
      06D5 1579 :
      06D5 1580 :
      06D5 1581 :
      06D5 1582 :
      06D5 1583 :
      06D5 1584 :
      06D5 1585 :
      06D5 1586 :
      06D5 1587 :
      06D5 1588 :
      06D5 1589 100$: ENBINT ;Allow device interrupts
      05 06D8 1590 RSB ;Return
      FEB4 06D9 1591 .WORD DD_TIME_OUT- ;Offset to timeout routine
      06DB 1592 :
      06DB 1593 :
      06DB 1594 :
      06DB 1595 :
      06DB 1596 :
      06DB 1597 :
      06DB 1598 :
      10 A5 53 7D 06DB 1599 200$: MOVQ R3,UCB$LD_FR3(R5) ;Save R3 and R4
      3F BA 06DF 1600 250$: POPR #M<R0,RT,R2,R3,R4,R5> ;Restore registers from the interrupt
      02 06E1 1601 REI ;Dismiss the interrupt
      FEAB 06E2 1602 .WORD DD_TIME_OUT- ;Offset to timeout routine
      06E4 1603 :
      06E4 1604 :
      06E4 1605 :
      06E4 1606 :
      06E4 1607 :
      51 1D DB 06E4 1608 300$: MFPR #PRS_CSRD,R1 ;Dump receiver buffer to R1
      1F 1D DA 06E7 1609 MTPR #ACK_CHAR,#PRS_CSTD ;Send ack. character
      83 51 90 06EA 1610 400$: MOVQ R1,(R3)+ ;Put byte in message buffer
      EB 54 F5 06ED 1611 SOBGTR R4,200$ ;Branch if more to go
      06F0 1612 :
      06F0 1613 :
      06F0 1614 :
      06F0 1615 :
      1C 00 DA 06F0 1616 500$: MTPR #0,#PRS_CSRS ;Disable device interrupts
      03 AA 06F3 1617 BISW #UCB$M_TIM:UCB$M_INT,- ;Clear INTERRUPT and TIMEOUT enabled
      64 A5 06F5 1618 UCB$W_STS(R5)
      FFFFFFFE2 EF 9F 06F7 1619 PUSHAB L*250$ ;Set return address of 'caller's caller'
```

This code is executed for the first byte received from the device. All succeeding interrupts for bytes received will go through another path, which is faster. This is done to save several instructions that need not be executed again. Note for this path the IPL must be restored before returning to the caller's caller. Failure to do so will cause a BUGCHECK in the fork process dispatcher. Note that R3 and R4 have already been saved, so it is not necessary to do so again. Also note that since interrupts and timeouts are not disabled until all the data has been transferred, it is not necessary to set the INTERRUPT and TIMEOUT enable bits for each byte transferred. For that reason, the timeout time is computed only once, and is large enough to allow time to transfer the maximum number of bytes possible, which is 128 bytes of data plus some RSP protocol overhead.

This is the fast interrupt service loop for MRSP protocol data transfers. This path exists to save testing the MRSP bit in the UCB for each byte transferred. Note that the interrupt is dispatched here to avoid the cost of an RSB back to the device's interrupt dispatcher. Of course the interrupt dispatcher Jumps here.

Dump the receiver buffer (word sized) into R1. After saving the data, acknowledge the receipt of the data. This will cause the TUSB to send the next byte, if any.

The data has been transferred. Disable device interrupts and create a fork process to continue on with the I/O operation.

				06FD	1620	IOFORK		;Get back to fork context
50	0838	8F	3C	0703	1621	MOVZWL	#SS\$ DATAOVERUN,R0	;Always return overrun status
	009C	D5	17	0708	1622	JMP	@UCB\$L_DPC(R5)	;Return
				070C	1623	:		
				070C	1624	:		
				070C	1625	:		
				070C	1626	:		
				070C	1627	:		
				070C	1628	:		
				070C	1629	:		
				070C	1630	:		
				070E	1631	600\$:	.WORD DD TIME OUT-	;Offset to timeout routine
	51	1D	DB	0711	1632	MFPRL	#PR\$ CSRD,R1	;Dump receiver buffer to R1
	D5	51	OF	E1	0711	BBC	#DD RBUF V ERROR,R1,400\$	;Branch if no overrun
009C	C5	FFFFFE49	EF	DE	0715	MOVAL	L^CONT_ERROR,UCB\$L_DPC(R5)	;Return to controller reset routine
			DO	11	071E	BRB	500\$	;Branch to common exit code

EMB
END
ERL
ERL
EXE
EXE
EXE
EXE
EXE
EXE
EXE
EXE
EXE
EXE
EXE
FUN
GET
GET
GET
HIG
IDB
INI
IOS
IOS
IOS
IOS
IOS
IOS
IOS
IOS
IOS
IOS
IOS
IOS
IOS
IOS
IOS
IOS
IOS
IOS
IOS
IOS
IOS
IOS
IOC
IOC
IOC
IOC
IOC
IOC
IOC

```

0720 1636 .SBTTL SEND_PACKET_C
0720 1637 :++
0720 1638 :
0720 1639 SEND_PACKET_C
0720 1640 :
0720 1641 ABSTRACT: Send a message packet to a console TUS8. Because of
0720 1642 the unique nature of the TUS8, this routine is optimized
0720 1643 for speed. The TUS8 generates an inordinate number of
0720 1644 interrupts, and can use a large fraction of the processor
0720 1645 during normal operation. In order to reduce overhead, some
0720 1646 extreme measures have been taken in the coding of this routine.
0720 1647 :
0720 1648 INPUT: R4 = CSR address
0720 1649 R5 = UCB address
0720 1650 UCBSL_DD_MSGPKT(R5) = Message packet buffer address
0720 1651 UCBSW_DD_MSGLEN(R5) = Message packet buffer length
0720 1652 :
0720 1653 OUTPUT: None.
0720 1654 :
0720 1655 NOTES:
0720 1656 :
0720 1657 1) This routine enables the device interrupts at the
0720 1658 beginning of the message packet and does not
0720 1659 disable them until the entire message packet has
0720 1660 been transferred.
0720 1661 :
0720 1662 2) The WFIKPC macro is not used. Instead, the code
0720 1663 is placed inline to avoid the cost in time inherent
0720 1664 in the macro.
0720 1665 :
0720 1666 3) To save the overhead of IOFORKing after each byte
0720 1667 transferred, the routine will not IOFORK until
0720 1668 the entire message packet has been transferred.
0720 1669 :
0720 1670 :
0720 1671 :--
0720 1672 SEND_PACKET_C: ;Send a message packet (console)
0720 1673 :
0720 1674 The following code needs to be done only once, to
0720 1675 set things up for the interrupt service loop.
0720 1676 :
009C C5 8E D0 0720 1677 MOVL (SP)+,UCBSL_DPC(R5) ;Store return address
0040 8F AA 0720 1678 BICW #UCBSM_TIMEOUT,- ;Clear timeout occurred bit
64 A5 0720 1679 UCBSW_STS(R5) ;
OC A5 00000769'EF DE 0720 1680 MOVAL L^300$,UCBSL_FPC(R5) ;Save interrupt dispatch address
00D4 C5 D0 0720 1681 MOVL UCBSL_DD_MSGPKT(R5),- ;Get address of message packet
10 A5 0720 1682 UCBSL_FR3(R5) ;
00D8 C5 3C 0720 1683 MOVZWL UCBSW_DD_MSGLEN(R5),- ;Get length of message
14 A5 0720 1684 UCBSL_FR4(R5) ;
0720 1685 DSBINT UCBSB_DIPL(R5) ;Lock out device interrupts
1E 00000040 8F DA 0720 1686 MTPR #DD_XCSR_M_TIE,#PRS_CSTS;Enable transmitter interrupts
03 AB 0720 1687 BISW #UCBSM_TINT,UCBSM_INT,- ;Set INTERRUPT and TIMEOUT enabled
64 A5 0720 1688 UCBSW_STS(R5) ;
34 C1 0720 1689 ADDL3 #LONG_WAIT,- ;Compute timeout time for entire transfer.
00000000'GF 0720 1690 G^EXESGL ABSTIM,- ;This will save recomputing it for each
6C A5 0720 1691 UCBSL_DUETIM(R5) ;byte transferred.
0720 1692 :

```

```

075A 1693 : This code is executed for the first byte received from the device.
075A 1694 : All succeeding interrupts for bytes received will go through
075A 1695 : another path, which is faster. This is done to save several
075A 1696 : instructions that need not be executed again. Note for this path
075A 1697 : the IPL must be restored before returning to the caller's caller.
075A 1698 : Failure to do so will cause a BUGCHECK in the fork process dispatcher.
075A 1699 : Note that R3 and R4 have already been saved, so it is not necessary
075A 1700 : to do so again. Also note that since interrupts and timeouts are not
075A 1701 : disabled until all the data has been transferred, it is not necessary
075A 1702 : to set the INTERRUPT and TIMEOUT enable bits for each byte transferred.
075A 1703 : For that reason, the timeout time is computed only once, and is large
075A 1704 : enough to allow time to transfer the maximum number of bytes possible,
075A 1705 : which is 128 bytes of data plus some RSP protocol overhead.
075A 1706 :
075A 1707 100$: ENBINT ;Allow device interrupts
05 RSB ;Return
FE2F 075D 1708 .WORD DD_TIME_OUT-. ;Offset to timeout routine
075E 1709
0760 1710 :
0760 1711 : This is the second and faster path through the wait-for-
0760 1712 : interrupt-and-keep-channel logic. It is reasonable to have
0760 1713 : two paths, as the first path is only needed for the first
0760 1714 : byte sent, and there will always be at least 14 bytes (the
0760 1715 : length of a command packet) sent. This path saves two instructions,
0760 1716 : as it would be necessary to save and restore the IPL in the
0760 1717 : other path. Note that the interrupt is dismissed here. This
0760 1718 : is to save the necessary RSB to return to the interrupt dispatcher.
0760 1719 : Of course the driver's interrupt dispatch JMPs to the location
0760 1720 : stored in UCB$L_FPC within the device UCB.
0760 1721 :
10 A5 53 7D 0760 1722 200$: MOVQ R3,UCB$L_FR3(R5) ;Save R3 and R4
3F BA 0764 1723 250$: POPR #*M<R0,RT,R2,R3,R4,R5> ;Restore registers from the interrupt
02 0766 1724 REI ;Dismiss the interrupt
FE26 0767 1725 .WORD DD_TIME_OUT-. ;Offset to timeout routine
0769 1726 :
0769 1727 : Get the data byte from the packet buffer and send it
0769 1728 : to the device. If there is more data to send, go through
0769 1729 : the second wait-for-interrupt-keep-channel path.
0769 1730 :
51 83 9A 0769 1731 300$: MOVZBL (R3)+,R1 ;Get data byte and point to next byte
1F 51 DA 076C 1732 MTPR R1,#PRS_CSTD ;Send data byte
00DC C5 51 B0 076F 1733 MOVW R1,UCB$W_DD_XBUF(R5) ;Save data byte (register is write-only)
E9 54 F5 0774 1734 SOBGTR R4,200$ ;Loop if more data
0777 1735 :
0777 1736 : The data has been transferred. Disable device interrupts
0777 1737 : and create a fork process to continue on with the I/O operation.
0777 1738 :
03 AA 0777 1739 BICW #UCB$M_TIM!UCB$M_INT,- ;Clear INTERRUPT and TIMEOUT enabled
64 A5 0779 1740 UCB$W_STS(R5)
1E 00 DA 077B 1741 MTPR #0,#PRS_CSTS ;Disable device interrupts
FFFFFFE0 EF 9F 077E 1742 PUSHAB L^250$ ;Set return address of 'caller's caller'
009C D5 17 0784 1743 IOFORK ;Get back to fork context
078A 1744 JMP @UCB$L_DPC(R5) ;Return

```

```
078E 1746 .SBTTL GET_PACKET_U
078E 1747 :++
078E 1748 :
078E 1749 : GET_PACKET_U
078E 1750 :
078E 1751 : ABSTRACT: Get a message packet from a unibus TU58. Because of
078E 1752 : the unique nature of the TU58, this routine is optimized
078E 1753 : for speed. The TU58 generates an inordinate number of
078E 1754 : interrupts, and can use a large fraction of the processor
078E 1755 : during normal operation. In order to reduce overhead, some
078E 1756 : extreme measures have been taken in the coding of this routine.
078E 1757 :
078E 1758 : INPUT: R4 = CSR address
078E 1759 : R5 = UCB address
078E 1760 : UCB$$_DD_MSGPKT(R5) = Message packet buffer address
078E 1761 : UCB$$_DD_MSGLEN(R5) = Message packet buffer length
078E 1762 :
078E 1763 : OUTPUT: None.
078E 1764 :
078E 1765 : NOTES:
078E 1766 : 1) This routine enables the device interrupts at the
078E 1767 : beginning of the message packet and does not
078E 1768 : disable them until the entire message packet has
078E 1769 : been transferred.
078E 1770 :
078E 1771 : 2) The WFIKPC macro is not used. Instead, the code
078E 1772 : is placed inline to avoid the cost in time inherent
078E 1773 : in the macro.
078E 1774 :
078E 1775 : 3) To save the overhead of IOFORKing after each byte
078E 1776 : transferred, the routine will not IOFORK until
078E 1777 : the entire message packet has been transferred.
078E 1778 :
078E 1779 : 4) The large time (40 seconds) spent waiting for a device timeout
078E 1780 : is necessary because of the slowness of the TU58. It takes on
078E 1781 : the order of 30 - 40 seconds for the device to position the
078E 1782 : tape from one end of the cartridge to another.
078E 1783 :
078E 1784 : --
078E 1785 :
078E 1786 GET_PACKET_U: ;Get a message packet
078E 1787 :
078E 1788 : The following code is done only once, to set up
078E 1789 : for the optimized interrupt service loop.
078E 1790 :
078E 1791 : MOVL (SP)+,UCB$$_DPC(R5) ;Store return address
078E 1792 : BICW #UCB$$_TIMOUT,- ;Clear timeout occurred bit
078E 1793 : UCB$$_STS(R5) ;
078E 1794 :
078E 1795 : If this is an MRSP TU58 then set the interrupt dispatch address to
078E 1796 : point to the code that will handle the MRSP protocol. Otherwise,
078E 1797 : set the dipatch address to a routine to handle the normal RSP TU58.
078E 1798 :
078E 1799 : MOVAL L*300$,UCB$$_FPC(R5) ;Assume this is an MRSP TU58.
078E 1800 : BBS #DD_V_USEMRSP,- ;Branch if we are to use MRSP
078E 1801 : UCB$$_TU58STS(R5),10$ ;
078E 1802 : MOVAL L*600$,UCB$$_FPC(R5) ;Set address for RSP TU58
```

009C C5 8E DO 078E 1791
0040 8F AA 0793 1792
64 A5 0797 1793
0799 1794
0799 1795
0799 1796
0799 1797
0799 1798
OC A5 000007E1'EF DE 0799 1799
03 E0 07A1 1800
08 00CA C5 07A3 1801
OC A5 00000810'EF DE 07A7 1802

```
00D4 C5 D0 07AF 1803 10$: MOVL UCB$LD MSGPKT(R5),- ;Get address of message packet
      10 A5      07B3 1804      UCB$LD FR3(R5)
14 A5 54 D0 07B5 1805      MOVL R4,UCB$LD FR4(R5) ;Save CSR address
      07B9 1806      DSBINT UCB$B DIPL(R5) ;Lock out device interrupts
64 0040 8F B0 07C0 1807      MOVW #DD RCSR M RIE,DD RCSR(R4);Enable receiver interrupts
      03 A8 07C5 1808      BISW #UCB$M TIM:UCB$M_INT,- ;Set INTERRUPT and TIMEOUT enabled
      64 A5      07C7 1809      UCB$W STS(R5)
      34 C1 07C9 1810      ADDL3 #LONG-WAIT,- ;Compute timeout time for entire transfer.
00000000 GF 07CB 1811      G^EXE$GL ABSTIM,- ;This will save recomputing it for each
      6C A5      07D0 1812      UCB$LD DUETIM(R5) ;byte transferred.
      07D2 1813 :
      07D2 1814 :
      07D2 1815 :
      07D2 1816 :
      07D2 1817 :
      07D2 1818 :
      07D2 1819 :
      07D2 1820 :
      07D2 1821 :
      07D2 1822 :
      07D2 1823 :
      07D2 1824 :
      07D2 1825 :
      07D2 1826 :
      07D2 1827 :
      07D2 1828 100$: ENBINT ;Allow device interrupts
      05 07D5 1829      RSB ;Return
      FDB7 07D6 1830      .WORD DD_TIME_OUT-. ;Offset to timeout routine
      07D8 1831 :
      07D8 1832 :
      07D8 1833 :
      07D8 1834 :
      07D8 1835 :
      07D8 1836 :
      07D8 1837 :
10 A5 53 7D 07D8 1838 200$: MOVQ R3,UCB$LD FR3(R5) ;Save R3 and R4
      3F BA 07DC 1839 250$: POPR #*M<R0,RT,R2,R3,R4,R5> ;Restore registers from the interrupt
      02 07DE 1840      REI ;Dismiss the interrupt
      FDAE 07DF 1841      .WORD DD_TIME_OUT-. ;Offset to timeout routine
      07E1 1842 :
      07E1 1843 :
      07E1 1844 :
      07E1 1845 :
      07E1 1846 :
51 02 A4 3C 07E1 1847 300$: MOVZWL DD RBUF(R4),R1 ;Dump receiver buffer to R1
06 A4 10 B0 07E5 1848      MOVW #ACK CHAR,DD_XBUF(R4) ;Send ack. character
      83 51 90 07E9 1849      MOVW R1,(R3)+ ;Put byte in message buffer
      00D8 C5 B7 07EC 1850      DECW UCB$W_DD_MSGLEN(R5) ;Decrement byte count
      E6 14 07F0 1851      BGTR 200$ ;Branch if more to go
      07F2 1852 :
      07F2 1853 :
      07F2 1854 :
      07F2 1855 :
      64 00 B0 07F2 1856 500$: MOVW #0,DD RCSR(R4) ;Disable receiver interrupts
      03 AA 07F5 1857      BICW #UCB$M TIM:UCB$M_INT,- ;Clear INTERRUPT and TIMEOUT enabled
      64 A5 07F7 1858      UCB$W STS(R5)
      FFFFFFDD EF 9F 07F9 1859      PUSHAB L^250$ ;Set return address of "caller's caller"
```

This code is executed for the first byte received from the device. All succeeding interrupts for bytes received will go through another path, which is faster. This is done to save several instructions that need not be executed again. Note for this path the IPL must be restored before returning to the caller's caller. Failure to do so will cause a BUGCHECK in the fork process dispatcher. Note that R3 and R4 have already been saved, so it is not necessary to do so again. Also note that since interrupts and timeouts are not disabled until all the data has been transferred, it is not necessary to set the INTERRUPT and TIMEOUT enable bits for each byte transferred. For that reason, the timeout time is computed only once, and is large enough to allow time to transfer the maximum number of bytes possible, which is 128 bytes of data plus some RSP protocol overhead.

This is the fast interrupt service loop for MRSP protocol data transfers. This path exists to save testing the MRSP bit in the UCB for each byte transferred. Note that the interrupt is dispatched here to avoid the cost of an RSB back to the device's interrupt dispatcher. Of course the interrupt dispatcher Jumps here.

Dump the receiver buffer (word sized) into R1. After saving the data, acknowledge the receipt of the data. This will cause the TUSB to send the next byte, if any.

The data has been transferred. Disable device interrupts and create a fork process to continue on with the I/O operation.

```

50  0838 8F 3C 07FF 1860 IOFORK ;Get back to fork context
    009C D5 17 0805 1861 MOVZWL #SS$ DATAOVERUN,R0 ;Always return overrun status
    080A 1862 JMP @UCB$L_DPC(R5) ;Return
    080E 1863 ;
    080E 1864 ; (check for data overrun. If an overrun occurred, disable
    080E 1865 ; device interrupts and get back to fork context. Then
    080E 1866 ; reset the controller. Note that no overruns will (should)
    080E 1867 ; occur when using MRSP, so this test does not have to be made
    080E 1868 ; for MRSP TUSBs.
    080E 1869 ;
    080E 1870 ;
    0810 1871 600$: .WORD DD_TIME_OUT- ;Offset to timeout routine
    0814 1872 MOVZWL DD-RBUF(R4),R1 ;Dump receiver buffer to R1
    0818 1873 BBC #DD-RBUF V ERROR,R1,400$ ;Branch if no overrun
    0821 1874 MOVAL L^CONT_ERROR,UCB$L_DPC(R5);Return to controller reset routine
    CF 11 BRB 500$ ;Branch to common exit code

S1 02 A4 FD7F 080E 1870
D1 S1 OF E1 0810 1871
009C C5 FFFF FD46 EF DE 0814 1872
CF 11 0818 1873
0821 1874
```

```
0823 1876 .SBTTL SEND_PACKET_U
0823 1877 :++
0823 1878 :
0823 1879 : SEND_PACKET_U
0823 1880 :
0823 1881 : ABSTRACT: Send a message packet to a unibus TU58. Because of
0823 1882 : the unique nature of the TU58, this routine is optimized
0823 1883 : for speed. The TU58 generates an inordinate number of
0823 1884 : interrupts, and can use a large fraction of the processor
0823 1885 : during normal operation. In order to reduce overhead, some
0823 1886 : extreme measures have been taken in the coding of this routine.
0823 1887 :
0823 1888 : INPUT: R4 = CSR address
0823 1889 : R5 = UCB address
0823 1890 : UCB$LD_MSGPKT(R5) = Message packet buffer address
0823 1891 : UCB$LD_MSGLEN(R5) = Message packet buffer length
0823 1892 :
0823 1893 : OUTPUT: None.
0823 1894 :
0823 1895 : NOTES:
0823 1896 :
0823 1897 : 1) This routine enables the device interrupts at the
0823 1898 : beginning of the message packet and does not
0823 1899 : disable them until the entire message packet has
0823 1900 : been transferred.
0823 1901 :
0823 1902 : 2) The WFIKPC macro is not used. Instead, the code
0823 1903 : is placed inline to avoid the cost in time inherent
0823 1904 : in the macro.
0823 1905 :
0823 1906 : 3) To save the overhead of IOFORKing after each byte
0823 1907 : transferred, the routine will not IOFORK until
0823 1908 : the entire message packet has been transferred.
0823 1909 :
0823 1910 :--
0823 1911 SEND_PACKET_U: ;Send a message packet (unibus)
0823 1912 :
0823 1913 : The following code needs to be done only once, to
0823 1914 : set things up for the interrupt service loop.
0823 1915 :
0823 1916 MOVL (SP)+,UCB$LD_DPC(R5) ;Store return address
0823 1917 BICW #UCB$LD_TIMEOUT,- ;Clear timeout occurred bit
0823 1918 UCB$LD_STS(R5) ;
0823 1919 MOVAL L^300$,UCB$LD_FPC(R5) ;Save interrupt dispatch address
0823 1920 MOVL UCB$LD_DD_MSGPKT(R5),- ;Get address of message packet
0823 1921 UCB$LD_FR3(R5) ;
0823 1922 MOVL R4,UCB$LD_FR4(R5) ;Save CSR address
0823 1923 DSBINT UCB$LD_DIPL(R5) ;Lock out device interrupts
0823 1924 MOVW #DD_XCSR_M_TIE,DD_XCSR(R4);Enable transmitter interrupts
0823 1925 BISW #UCB$LD_TIMEOUT,UCB$LD_INT,- ;Set INTERRUPT and TIMEOUT enabled
0823 1926 UCB$LD_STS(R5) ;
0823 1927 ADDL3 #LONG_WAIT,- ;Compute timeout time for entire transfer.
0823 1928 G^EXE$GL ABSTIM,- ;This will save recomputing it for each
0823 1929 UCB$LD_DUETIM(R5) ;byte transferred.
0823 1930 :
0823 1931 : This code is executed for the first byte received from the device.
0823 1932 : All succeeding interrupts for bytes received will go through
```

```
009C C5 8E D0 0823 1916 MOVL (SP)+,UCB$LD_DPC(R5) ;Store return address
0040 8F AA 0828 1917 BICW #UCB$LD_TIMEOUT,- ;Clear timeout occurred bit
64 A5 082C 1918 UCB$LD_STS(R5) ;
OC A5 00000869'EF DE 082E 1919 MOVAL L^300$,UCB$LD_FPC(R5) ;Save interrupt dispatch address
00D4 C5 D0 0836 1920 MOVL UCB$LD_DD_MSGPKT(R5),- ;Get address of message packet
10 A5 083A 1921 UCB$LD_FR3(R5) ;
14 A5 54 D0 083C 1922 MOVL R4,UCB$LD_FR4(R5) ;Save CSR address
04 A4 0040 8F B0 0840 1923 DSBINT UCB$LD_DIPL(R5) ;Lock out device interrupts
03 A8 0847 1924 MOVW #DD_XCSR_M_TIE,DD_XCSR(R4);Enable transmitter interrupts
64 A5 084D 1925 BISW #UCB$LD_TIMEOUT,UCB$LD_INT,- ;Set INTERRUPT and TIMEOUT enabled
34 C1 084F 1926 UCB$LD_STS(R5) ;
00000000'GF 0851 1927 ADDL3 #LONG_WAIT,- ;Compute timeout time for entire transfer.
6C A5 0853 1928 G^EXE$GL ABSTIM,- ;This will save recomputing it for each
0858 1929 UCB$LD_DUETIM(R5) ;byte transferred.
085A 1930 :
085A 1931 : This code is executed for the first byte received from the device.
085A 1932 : All succeeding interrupts for bytes received will go through
```

```
085A 1933 : another path, which is faster. This is done to save several
085A 1934 : instructions that need not be executed again. Note for this path
085A 1935 : the IPL must be restored before returning to the caller's caller.
085A 1936 : Failure to do so will cause a BUGCHECK in the fork process dispatcher.
085A 1937 : Note that R3 and R4 have already been saved, so it is not necessary
085A 1938 : to do so again. Also note that since interrupts and timeouts are not
085A 1939 : disabled until all the data has been transferred, it is not necessary
085A 1940 : to set the INTERRUPT and TIMEOUT enable bits for each byte transferred.
085A 1941 : For that reason, the timeout time is computed only once, and is large
085A 1942 : enough to allow time to transfer the maximum number of bytes possible,
085A 1943 : which is 128 bytes of data plus some RSP protocol overhead.
085A 1944 :
05 085A 1945 100$: ENBINT ;Allow device interrupts
FD2F 085D 1946 RSB ;Return
085E 1947 .WORD DD_TIME_OUT-. ;Offset to timeout routine
0860 1948 :
0860 1949 : This is the second and faster path through the wait-for-
0860 1950 : interrupt-and-keep-channel logic. It is reasonable to have
0860 1951 : two paths, as the first path is only needed for the first
0860 1952 : byte sent, and there will always be at least 14 bytes (the
0860 1953 : length of a command packet) sent. This path saves two instructions,
0860 1954 : as it would be necessary to save and restore the IPL in the
0860 1955 : other path. Note that the interrupt is dismissed here. This
0860 1956 : is to save the necessary RSB to return to the interrupt dispatcher.
0860 1957 : Of course the driver's interrupt dispatch JMPs to the location
0860 1958 : stored in UCB$$_FPC within the device UCB.
0860 1959 :
10 A5 53 7D 0860 1960 200$: MOVQ R3,UCB$$_FPC(R5) ;Save R3 and R4
3F BA 0864 1961 250$: POPR #^M<R0,RT,R2,R3,R4,R5> ;Restore registers from the interrupt
02 0866 1962 REI ;Dismiss the interrupt
FD26 0867 1963 .WORD DD_TIME_OUT-. ;Offset to timeout routine
0869 1964 :
0869 1965 : Get the data byte from the packet buffer and send it
0869 1966 : to the device. If there is more data to send, go through
0869 1967 : the second wait-for-interrupt-keep-channel path.
0869 1968 :
06 A4 83 9B 0869 1969 300$: MOVZBW (R3)+,DD_XBUF(R4) ;Send the data to the TUS8
00D8 C5 B7 086D 1970 DECB UCB$$_DD_MSGLEN(R5) ;Decrement byte count
ED 14 0871 1971 BGTR 200$ ;Branch if more to send
0873 1972 :
0873 1973 : The data has been transferred. Disable device interrupts
0873 1974 : and create a fork process to continue on with the I/O operation.
0873 1975 :
03 AA 0873 1976 BICW #UCB$$_TIM!UCB$$_INT,- ;Clear INTERRUPT and TIMEOUT enabled
64 A5 0875 1977 UCB$$_STS(R5) ;
04 A4 00 B0 0877 1978 MOVW #0,DD_XCSR(R4) ;Disable transmitter interrupts
FFFFFFE3 EF 9F 087B 1979 PUSHAB L^250$ ;Set return address of 'caller's caller'
009C D5 17 0881 1980 IOFORK ;Get back to fork context
0887 1981 JMP @UCB$$_DPC(R5) ;Return
```

```

088B 1983 :++
088B 1984 :
088B 1985 : SCSR
088B 1986 :
088B 1987 : ABSTRACT: Update the transmitter CSR with the data in R1.
088B 1988 :
088B 1989 : INPUT: R1 = CSR image
088B 1990 : R4 = CSR address
088B 1991 :
088B 1992 : OUTPUT: CSR updated
088B 1993 :
088B 1994 : SIDE EFFECTS: None
088B 1995 :
088B 1996 :--
088B 1997 : SCSR:
04 00CA 00 E1 088B 1998 BBC #DD_V_CONSOLE,- :Branch if not console device
1E 51 DA 088D 1999 UCB$W-TU58STS(R5),10$ :
05 0891 2000 MTPR R1,#PRS_CSTS :Update CSR
05 0894 2001 RSB :Return
04 A4 51 B0 0895 2002 10$: MOVW R1,DD_XCSR(R4) :Update CSR
05 0899 2003 RSB :Return

```

- TUSB DC100 TAPE CARTRIDGE DRIVER
SEND_PACKET_U

Page 49
(1)

```

089A 2005 :++
089A 2006
089A 2007 : RCSR
089A 2008
089A 2009 : ABSTRACT:      Update the receiver CSR with the data in R1.
089A 2010
089A 2011 : INPUT:          R1 = CSR image
089A 2012 :                   R4 = CSR address
089A 2013
089A 2014 : OUTPUT:         CSR updated
089A 2015
089A 2016 : SIDE EFFECTS: None
089A 2017
089A 2018 :--
089A 2019 RCSR:
089A 2020 BBC          #DD V_CONSOLE,-          ;Branch if not console device
089C 2021          UCB$W-TU58STS(R5),10$      ;
08A0 2022          MTPR          R1,#PR$_CSRS  ;Update CSR
08A3 2023          RSB          ;Return
08A4 2024 10$:      MOVW          R1,DD_RCSR(R4) ;Update CSR
08A7 2025          RSB          ;Return

```

```

08A8 2027 :++
08A8 2028 :
08A8 2029 : CHECKSUM
08A8 2030 :
08A8 2031 : ABSTRACT: Given a message packet buffer address and length,
08A8 2032 : compute the checksum of the buffer. The checksum
08A8 2033 : is formed by adding adjacent words in the buffer and
08A8 2034 : adding in the carry (if any).
08A8 2035 :
08A8 2036 : INPUT: R1 = Message packet buffer address.
08A8 2037 : R2 = Message packet buffer length.
08A8 2038 : R5 = UCB address.
08A8 2039 :
08A8 2040 : OUTPUT: R0 = Checksum (low word)
08A8 2041 :
08A8 2042 :
08A8 2043 : SIDE EFFECTS: R1,R2 are overwritten.
08A8 2044 :
08A8 2045 :--
08A8 2046 : CHECKSUM:
08A8 2047 : PUSH R2 ;Create message packet checksum
08AA 2048 : CLRL R0 ;Save byte count on stack
08AC 2049 : ASHL #1,R2,R2 ;Clear output cell
10$: 08B1 2050 : ADDW (R1)+,R0 ;Convert byte count to word count
08B4 2051 : ADWC #0,R0 ;Add word to current checksum
08B7 2052 : SOBGTR R2,10$ ;Add in carry, if any
08BA 2053 : ;Branch if not done
08BA 2054 :
08BA 2055 : In order to make CHECKSUM work for odd byte counts, we
08BA 2056 : have add the last byte on after calculating the checksum
08BA 2057 : for the rest of the buffer.
01 8E E8 08BA 2058 : BLBS (SP)+,20$ ;Branch if odd byte count
05 08BD 2059 : RSB ;Return
52 81 9A 08BE 2060 20$: MOVZBL (R1)+,R2 ;Get the last byte in the buffer
50 52 A0 08C1 2061 : ADDW R2,R0 ;Add it to the checksum
50 00 D8 08C4 2062 : ADWC #0,R0 ;Add in carry, if any
05 08C7 2063 : RSB ;Return

```

```
08C8 2065 :++
08C8 2066 :
08C8 2067 : SET_FUNCTION
08C8 2068 :
08C8 2069 : ABSTRACT: Use the function code in the IRP to determine which TU58
08C8 2070 : function to perform. In effect, map the system function
08C8 2071 : code into a TU58 function code. The results are returned
08C8 2072 : in the low bytes of R0 and R1.
08C8 2073 :
08C8 2074 : INPUT: R5 = UCB ADDRESS
08C8 2075 :
08C8 2076 : OUTPUT: R0 = TU58 FUNCTION CODE
08C8 2077 : R1 = TU58 FUNCTION CODE MODIFIER
08C8 2078 : Mapping bit in UCB$W_TU58STS is set or cleared, depending
08C8 2079 : on the function requested.
08C8 2080 :
08C8 2081 : SIDE EFFECTS: R3 = IRP ADDRESS
08C8 2082 :
08C8 2083 : NOTE: Some functions listed as legal in the FDT are not yet
08C8 2084 : implemented in the TU58 firmware. These functions will
08C8 2085 : be trapped here and flagged as illegal function codes.
08C8 2086 : If an illegal function is requested, exit the driver
08C8 2087 : without sending a command packet.
08C8 2088 :
08C8 2089 :--
08C8 2090 : SET_FUNCTION: :Determine TU58 function
08C8 2091 :
08C8 2092 : If this TU58 speaks MRSP, assume that the function will
08C8 2093 : use MRSP unless the user explicitly requests otherwise.
08C8 2094 :
20 A3 B0 08C8 2095 : MOVW IRP$W_FUNC(R3),- :Copy function code to UCB
009A C5 08CB 2096 : UCB$W_FUNC(R5)
08C8 2097 : BBC #DD V_MRSP,- :Branch if not an MRSP TU58
11 00CA C5 08D0 2098 : UCB$W_TU58STS(R5),20$
08C8 2099 : BBBS #DD V_USEMRSP,- :Set to use MRSP
00 00CA C5 08D6 2100 : UCB$W_TU58STS(R5),10$
08C8 2101 : BBC #IOSV_NOMRSP,- :Branch if user wants to use MRSP
06 20 A3 08DC 2102 : IRP$W_FUNC(R3),20$
08C8 2103 : BBCC #DD V_USEMRSP,- :Do not use MRSP for this operation
00 00CA C5 08E1 2104 : UCB$W_TU58STS(R5),20$
08C8 2105 : 20$: CLRL R1 :Assume no function modifier
53 58 A5 D0 08E7 2106 : MOVL UCB$L_IRP(R5),R3 :Get IRP address
08C8 2107 : EXTZV :Extract the function code
08C8 2108 : #IRP$V_FCODE,-
08C8 2109 : #IRP$S_FCODE,-
50 20 A3 08EE 2109 : IRP$W_FUNC(R3),R0 :Put function code in R0
08C8 2110 : #IOS_READPBLK,R0 :READ physical block?
50 0C 91 08F1 2110 : CMPB 30$
08C8 2111 : BEQL 30$
50 0B 91 08F6 2112 : CMPB #IOS_WRITEPBLK,R0 :WRITE physical block?
08C8 2113 : BEQL 40$
50 09 91 08FB 2114 : CMPB #IOS_SEARCH,R0 :SEARCH/POSITION request?
08C8 2115 : BEQL 50$
50 1D 91 0900 2116 : CMPB #IOS_DIAGNOSE,R0 :DIAGNOSE function?
08C8 2117 : BNEQ 60$ :Branch if not
50 07 90 0905 2118 : MOVB #DD_CODE_DIAG,R0 :Set diagnose function
08C8 2119 : RSB :Return
50 02 90 0909 2120 : 30$: MOVB #DD_CODE_READ,R0 :Set READ function
08C8 2121 : BRB 45$ :Check for function modifier
```

```
50 03 90 090E 2122 40$: MOVB #DD_CODE_WRITE,R0 ;Set WRITE function
01 20 0E E0 0911 2123 45$: BBS #IOSV_DATACHECK,- ;Branch if DATACHECK requested
A3 0913 2124 ;
05 0916 2125 ;Return
51 01 90 0917 2126 46$: MOVB #DD_CODE_DATACHECK,R1 ;Set DATACHECK op code modifier
05 091A 2127 ;Return
50 05 90 091B 2128 50$: MOVB #DD_CODE_SEARCH,R0 ;Set SEARCH function
05 091E 2129 ;Return
091F 2130 ;
091F 2131 ; Trap UNLOAD, AVAILABLE and PACKACK functions here. These function simply
091F 2132 ; set or clear the valid bit in the UCB and return with success status. A
091F 2133 ; command packet is not sent.
091F 2134 ;
091F 2135 ;
50 01 91 091F 2136 60$: CMPB #IOS_UNLOAD,R0 ; Unload function?
05 13 0922 2137 ; BEQL 65$ ; Branch if so.
50 11 91 0924 2138 ; CMPB #IOS_AVAILABLE,R0 ; Available function?
08 12 0927 2139 ; BNEQ 70$ ; Branch if not.
0800 8F AA 0929 2140 65$: BICW #UCBSM_VALID,- ; Clear software valid bit.
64 A5 092D 2141 ; UCBSW_STS(R5)
0B 11 092F 2142 ; BRB 80$ ; Branch to common code.
50 08 91 0931 2143 70$: CMPB #IOS_PACKACK,R0 ; Pack acknowledge function?
0B 12 0934 2144 ; BNEQ 100$ ; Must be illegal function code.
0800 8F AB 0936 2145 ; BISW #UCBSM_VALID,- ; Set software volume valid bit.
64 A5 093A 2146 ; UCBSW_STS(R5)
50 01 D0 093C 2147 80$: MOVL #SSS_NORMAL,R0 ; Return success status.
05 11 093F 2148 ; BRB 2J0$ ; Branch to exit.
0941 2149 ;
0941 2150 ;
0941 2151 ; If we fall through all the tests, it is an illegal function.
0941 2152 ;
50 00F4 8F B0 0941 2153 100$: MOVW #SSS_ILLIOFUNC,R0 ;Put error status in R0
8E D5 0946 2154 200$: TSTL (SP)+ ;Discard return address
FBF1 31 0948 2155 ; BRW DD_EXIT ;Exit the driver NOW
094B 2156 ;
094B 2157 DD_END: ;ADDRESS OF LAST LOCATION IN DRIVER
094B 2158 ;
094B 2159 ;.END
```

DDDRIVER
Symbol table

- TUSB DC100 TAPE CARTRIDGE DRIVER

B 5

16-SEP-1984 00:19:23 VAX/VMS Macro V04-00
5-SEP-1984 00:12:11 [DRIVER.SRC]DDDRIVER.MAR;1

Page 53
(1)

DLI
V04

\$\$\$	= 00000020	R	02	DD_REGDUMP	00000621	R	03
\$\$OP	= 00000002			DD_RESTARTIO	00000273	R	03
ACK_CHAR	= 00000010			DD_RETRY	00000572	R	03
ACPSACCESS	*****	X	03	DD_SAVEREG	00000660	R	03
ACPSDEACCESS	*****	X	03	DD_STARTIO	0000026D	R	03
ACPSMODIFY	*****	X	03	DD_STS_BADCKSM	= FFFFFFFC6		
ACPSMOUNT	*****	X	03	DD_STS_BADDIAG	= FFFFFFFF		
ACPSREADBLK	*****	X	03	DD_STS_BADINIT	= FFFFFFFC7		
ACPSWRITEBLK	*****	X	03	DD_STS_BADOPCD	= FFFFFFFD0		
AT\$_UBA	= 00000001			DD_STS_BADRCD	= FFFFFFFC9		
BIT...	= 00000004			DD_STS_BADUNIT	= FFFFFFFF8		
CHECKSUM	000008A8	R	03	DD_STS_BLKNF	= FFFFFFFE0		
CMD_PKT_HDR	= 00000A02			DD_STS_DATACHK	= FFFFFFFEF		
CONT_ERROR	00000564	R	03	DD_STS_DATAOVR	= FFFFFFFC5		
CRB\$C_INTD	= 00000024			DD_STS_MTRSTOP	= FFFFFFFDF		
CRB\$C_INTD2	= 00000048			DD_STS_NOCART	= FFFFFFFF7		
DC\$_DISK	= 00000001			DD_STS_NORMAL	= 00000000		
DD\$DDT	00000000	RG	03	DD_STS_PARTOP	= FFFFFFFFE		
DDB\$K_TAPE	= 00000004			DD_STS_RETRY	= 00000001		
DDB\$C_ACPD	= 00000010			DD_STS_WRTLCK	= FFFFFFFF5		
DDB\$C_DDT	= 0000000C			DD_TIME_OUT	0000058D	R	03
DD_CHRSM_LEN	= 00000002			DD_TRYAGN	00000303	R	03
DD_CODE_DATACHECK	= 00000001			DD_UNIT_INIT	000000CC	R	03
DD_CODE_DETECT	= 0000000A			DD_UNSOENT	0000064E	R	03
DD_CODE_DIAG	= 00000007			DD_V_CONSOLE	= 00000000		
DD_CODE_READ	= 00000002			DD_V_MRSP	= 00000002		
DD_CODE_SEARCH	= 00000005			DD_V_PASS1	= 00000001		
DD_CODE_WRITE	= 00000003			DD_V_USEMRSP	= 00000003		
DD_CP_BCNT	= 0000000A			DD_XBUF	00000006		
DD_CP_LEN	= 0000000E			DD_XCSR	00000004		
DD_DATA	= 00000002			DD_XCSR_M_BREAK	= 00000001		
DD_DPBCNT	= 00000001			DD_XCSR_M_TIE	= 00000040		
DD_DPBUF_LEN	= 00000084			DD_XCSR_V_TRDY	= 00000007		
DD_END	0000094B	R	03	DEV\$M_AVL	= 00040000		
DD_EP_LEN	= 0000000E			DEV\$M_DIR	= 00000008		
DD_ERRBUF_LEN	= 0000002C			DEV\$M_ELG	= 00400000		
DD_ERRBUF_LEN_L	= 0000000B			DEV\$M_FOD	= 00004000		
DD_EXIT	0000053C	R	03	DEV\$M_IDV	= 04000000		
DD_FLAG_CNTL	= 00000002			DEV\$M_NNM	= 00000200		
DD_FLAG_CONT	= 00000010			DEV\$M_ODV	= 08000000		
DD_FLAG_DATA	= 00000001			DEV\$M_RND	= 10000000		
DD_FLAG_INIT	= 00000004			DEV\$M_SHR	= 00010000		
DD_FLAG_XOFF	= 00000013			DPT\$C_LENGTH	= 00000038		
DD_FUNC\$TABLE	00000038	R	03	DPT\$C_VERSION	= 00000004		
DD_INT	0000063C	RG	03	DPT\$INITAB	00000038	R	02
DD_MAX_PKT_BCNT	= 00000080			DPT\$M_SVP	= 00000002		
DD_M_CONSOLE	= 00000001			DPT\$REINITAB	00000085	R	02
DD_M_MRSP	= 00000004			DPT\$TAB	00000000	R	02
DD_M_PASS1	= 00000002			DTS_TUSB	= 0000000E		
DD_M_USEMRSP	= 00000008			DTECT_PKT_CHKSM	= 00000A0C		
DD_NOM_REGS	= 00000004			DTECT_PKT_HDR	= 000A0A02		
DD_PWF	000005B5	R	03	DUMP_RECVR_BUF	00000216	R	03
DD_RBUF	00000002			DYN\$C_BUFID	= 00000013		
DD_RBUF_V_ERROR	= 0000000F			DYN\$C_CRB	= 00000005		
DD_RCSR	00000000			DYN\$C_DDB	= 00000006		
DD_RCSR_M_RDONE	= 00000080			DYN\$C_DPT	= 0000001E		
DD_RCSR_M_RIE	= 00000040			DYN\$C_UCB	= 00000010		

EMBSL DV REGSAV	= 0000004E			IOCSREQPCANL	*****	X	03
END_PACKET	000004C0	R	03	IOCSRETURN	*****	X	03
ERL\$DEVICERR	*****	X	03	IRPSL_MEDIA	= 00000038		
ERL\$DEVICTMO	*****	X	03	IRPSL-SVAPTE	= 0000002C		
EXESALONONPAGED	*****	X	03	IRPSS-FCODE	= 00000006		
EXESGB_CPUTYPE	*****	X	03	IRPSV-DIAGBUF	= 00000007		
EXESGL-ABSTIM	*****	X	03	IRPSV-FCODE	= 00000000		
EXESGL-NONPAGED	*****	X	03	IRPSW-FUNC	= 00000020		
EXESGL-TENUSEC	*****	X	03	IRPSW-STS	= 0000002A		
EXESGL-UBDELAY	*****	X	03	LONG_WAIT	= 00000034		
EXESIOFORK	*****	X	03	MASKR	= 00000008		
EXESLCDSKVALID	*****	X	03	MASKL	= 04000000		
EXESONEPARM	*****	X	03	MAXCHRTIM	= 00004E20		
EXESSENSEMODE	*****	X	03	MRSP-M-SWITCH	= 00000008		
EXESSETCHAR	*****	X	03	MRSP-V-SWITCH	= 00000003		
EXESZEROPARM	*****	X	03	PR\$-CSRD	= 0000001D		
FUNCTAB_LEN	= 00000094			PR\$-CSRS	= 0000001C		
GET_PACKET-C	0000068D	R	03	PR\$-CSTD	= 0000001F		
GET_PACKET-U	0000078E	R	03	PR\$-CSTS	= 0000001E		
GET_RESPONSE	00000341	R	03	PR\$-IPL	= 00000012		
HIGH_DIPL	= 00000017			PR\$-SID-TYP730	= 00000003		
IDB\$C_CSR	= 00000000			PR\$-SID-TYP750	= 00000002		
INIT_UNIT	00000136	R	03	RCSR	0000089A	R	03
IOSV-DATACHECK	= 0000000E			READ_DATA	0000037D	R	03
IOSV-INHRETRY	= 0000000F			RESET_CONTROLLER	000005B8	R	03
IOSV-NOMRSP	= 00000006			SCSR	0000088B	R	03
IOS_ACCESS	= 00000032			SEND_PACKET-C	00000720	R	03
IOS-ACPCONTROL	= 00000038			SEND_PACKET-U	00000823	R	03
IOS-AVAILABLE	= 00000011			SET_FUNCTION	000008C8	R	03
IOS-CREATE	= 00000033			SHORT_WAIT	= 00000002		
IOS-DEACCESS	= 00000034			SIZ...	= 00000001		
IOS-DELETE	= 00000035			SND_PKT_NOINT	000001B2	R	03
IOS-DIAGNOSE	= 0000001D			SS\$-CTRERR	= 00000054		
IOS-MODIFY	= 00000036			SS\$-DATACHECK	= 0000005C		
IOS-MOUNT	= 00000039			SS\$-DATAOVERUN	= 00000838		
IOS-PACKACK	= 00000008			SS\$-ILLIOFUNC	= 000000F4		
IOS-READLBLK	= 00000021			SS\$-MEDOFL	= 000001A4		
IOS-READPBLK	= 0000000C			SS\$-NONEXDRV	= 000001C4		
IOS-READVBLK	= 00000031			SS\$-NORMAL	= 00000001		
IOS-SEARCH	= 00000009			SS\$-PARITY	= 000001F4		
IOS-SENSECHAR	= 0000001B			SS\$-TIMEOUT	= 0000022C		
IOS-SENSEMODE	= 00000027			SS\$-WRTTLCK	= 0000025C		
IOS-SETCHAR	= 0000001A			TWO-INITs	= 00000404		
IOS-SETMODE	= 00000023			UCB\$B-DD-BCNTH	000000EB		
IOS-UNLOAD	= 00000001			UCB\$B-DD-BCNTL	000000EA		
IOS-VIRTUAL	= 0000003F			UCB\$B-DD-BLKH	000000ED		
IOS-WRITELBK	= 00000020			UCB\$B-DD-BLKL	000000EC		
IOS-WRITEPBLK	= 0000000B			UCB\$B-DD-CPBCNT	000000E3		
IOS-WRITEVBLK	= 00000030			UCB\$B-DD-CPFLAG	000000E2		
IOCS\$DIAGBUF ILL	*****	X	03	UCB\$B-DD-EPBCNT	000000F1		
IOCS\$MNTVER	*****	X	03	UCB\$B-DD-EPCODE	000000F2		
IOCS\$MOVFRUSER	*****	X	03	UCB\$B-DD-EPFLAG	000000F0		
IOCS\$MOVFRUSER2	*****	X	03	UCB\$B-DD-EPSTS	000000F3		
IOCS\$MOVTOUSER	*****	X	03	UCB\$B-DD-EPUNIT	000000F4		
IOCS\$MOVTOUSER2	*****	X	03	UCB\$B-DD-OPCODE	000000E4		
IOCS\$RELCHAN	*****	X	03	UCB\$B-DD-OPMOD	000000E5		
IOCS\$REQCOM	*****	X	03	UCB\$B-DD-SEQH	000000E9		

DDDRIVER
Symbol table

- TU58 DC100 TAPE CARTRIDGE DRIVER D 5

16-SEP-1984 00:19:23 VAX/VMS Macro V04-00
5-SEP-1984 00:12:11 [DRIVER.SRC]DDDRIVER.MAR;1

Page 55
(1)

DLC
V04

UCBSB_DD_SEQL
UCBSB_DD_SWITCH
UCBSB_DD_UNIT
UCBSB_DEVCLASS
UCBSB_DEVTYPE
UCBSB_DIPL
UCBSB_ERTCNT
UCBSB_ERTMAX
UCBSB_FIPL
UCBSB_OFFNDX
UCBSB_SECTORS
UCBSB_SPR
UCBSB_TRACKS
UCBSK_DD_CPADDR
UCBSK_DD_EPADDR
UCBSK_DD_REGBUF
UCBSK_DD_UCBLEN
UCBSK_LCC_DISK_LENGTH
UCBSL_CRB
UCBSL_DD_BUFWIN
UCBSL_DD_DPTR
UCBSL_DD_MSGPKT
UCBSL_DEVCHAR
UCBSL_DEVCHAR2
UCBSL_DPC
UCBSL_DUETIM
UCBSL_FPC
UCBSL_FR3
UCBSL_FR4
UCBSL_IRP
UCBSL_MAXBLOCK
UCBSL_MEDIA
UCBSL_MEDIA_ID
UCBSL_SVAPTE
UCBSM_DIAGBUF
UCBSM_INT
UCBSM_TIM
UCBSM_TIMEOUT
UCBSM_VALID
UCBSV_INT
UCBSV_ONLINE
UCBSV_POWER
UCBSV_TIMEOUT
UCBSW_BCNT
UCBSW_BCR
UCBSW_CYLINDERS
UCBSW_DD_ABCNT
UCBSW_DD_CPCKSM
UCBSW_DD_EPCKSM
UCBSW_DD_MSGLEN
UCBSW_DD_RBUF
UCBSW_DD_RCSR
UCBSW_DD_SMSTS
UCBSW_DD_XBUF
UCBSW_DD_XCSR
UCBSW_DEVBUFSIZ
UCBSW_DEVSTS

000000E8
000000E7
000000E6
= 00000040
= 00000041
= 0000005E
= 00000080
= 00000081
= 0000000B
= 000000CA
= 00000044
= 00000091
= 00000045
000000E2
000000F0
000000CA
000000FE
= 000000CC
= 00000024
000000CC
000000D0
000000D4
= 00000038
= 0000003C
= 0000009C
= 0000006C
= 0000000C
= 00000010
= 00000014
= 00000058
= 000000B0
= 000000BC
= 0000008C
= 00000078
= 00000002
= 00000002
= 00000001
= 00000040
= 00000800
= 00000001
= 00000004
= 00000005
= 00000006
= 0000007E
= 000000C0
= 00000046
000000F8
000000EE
000000FC
000000D8
000000E0
000000DE
000000FA
000000DC
000000DA
= 00000042
= 00000068

UCBSW_FUNC
UCBSW_STS
UCBSW_TU58STS
UCBSW_UNIT
VECSL_IDB
VECSL_UNITINIT
WRITE_DATA
WRITE_WAIT

= 0000009A
= 00000064
= 000000CA
= 00000054
= 00000008
= 00000018
0000043A R 03
= 00000002

! Psect synopsis !

PSECT name	Allocation	PSECT No.	Attributes
-----	-----	-----	-----
. ABS .	00000000 (0.)	00 (0.)	NOPIC USR CON ABS LCL NOSHR NOEXE NORD NOWRT NOVEC BYTE
\$AB\$\$	000000FE (254.)	01 (1.)	NOPIC USR CON ABS LCL NOSHR EXE RD WRT NOVEC BYTE
\$\$\$105_PROLOGUE	0000009A (154.)	02 (2.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC BYTE
\$\$\$115_DRIVER	00000948 (2379.)	03 (3.)	NOPIC USR CON REL LCL NOSHR EXE RD WRT NOVEC LONG

! Performance indicators !

Phase	Page faults	CPU Time	Elapsed Time
-----	-----	-----	-----
Initialization	36	00:00:00.03	00:00:02.86
Command processing	130	00:00:00.39	00:00:03.23
Pass 1	614	00:00:19.05	00:01:11.16
Symbol table sort	0	00:00:02.67	00:00:06.95
Pass 2	384	00:00:04.85	00:00:16.80
Symbol table output	19	00:00:00.21	00:00:01.39
Psect synopsis output	0	00:00:00.02	00:00:00.02
Cross-reference output	0	00:00:00.00	00:00:00.00
Assembler run totals	1185	00:00:27.22	00:01:42.41

The working set limit was 2400 pages.
159747 bytes (313 pages) of virtual memory were used to buffer the intermediate code.
There were 130 pages of symbol table space allocated to hold 2399 non-local and 105 local symbols.
2159 source lines were read in Pass 1, producing 22 object records in Pass 2.
51 pages of virtual memory were used to define 48 macros.

! Macro library statistics !

Macro library name	Macros defined
-----	-----
-\$255\$DUA28:[SYS.OBJ]LIB.MLB;1	29
-\$255\$DUA28:[SYSLIB]STARLET.MLB;2	10
TOTALS (all libraries)	39


2612 GEIS were required to define 39 macros.

There were no errors, warnings or information messages.

MACRO/LIS=LIS\$:DDDRIVER/OBJ=OBJ\$:DDDRIVER MSRC\$:DDDRIVER/UPDATE=(ENH\$:DDDRIVER)+EXECMLS/LIB

0108 AH-BT13A-SE
VAX/VMS V4.0

DIGITAL EQUIPMENT CORPORATION
CONFIDENTIAL AND PROPRIETARY



0109 AH-BT13A-SE
VAX/VMS V4.0

DIGITAL EQUIPMENT CORPORATION
CONFIDENTIAL AND PROPRIETARY

